

***ski-doo***®



**2009**

**Operator's  
Guide** Includes  
Safety, Vehicle  
and Maintenance Information

**REV-XP™**

**⚠ WARNING**

Read this guide thoroughly.  
It contains important safety information.  
Minimum recommended operator's age: 16 years old.  
Do not remove this Operator's Guide from the vehicle.

**5 2 0 0 0 0 9 0 0**

**⚠ WARNING**

Disregarding any of the safety precautions and instructions contained in this Operator's Guide, *SAFETY DVD* and on-product labels could cause injury including the possibility of death!

**⚠ WARNING**

This vehicle may exceed the performance of other vehicles you may have ridden in the past. Take time to familiarize yourself with your new vehicle.

**CALIFORNIA PROPOSITION 65 WARNING**

**⚠ WARNING**

This product contains or emits chemicals known to the state of California to cause cancer and birth defects or other reproductive harm.



In USA, products are distributed by BRP US Inc.  
In Canada, products are distributed by Bombardier Recreational Products Inc.

The following are trademarks of Bombardier Recreational Products Inc. or its subsidiaries.

DESS™	RAVE™	ROTAX™	SUMMIT™
HPG™	RER™	SC™	TRA™
MX Z™	Renegade™	SKI-DOO®	X™
GSX™	REV-XP™	E-TEC®	GTX†

† Trademark of Castrol Limited used under license.

---

# FOREWORD

Congratulations on your purchase of a new SKI-DOO® snowmobile. Whatever model you have chosen, it is backed by the Bombardier Recreational Products Inc. (BRP) warranty and a network of authorized SKI-DOO snowmobile dealers ready to provide the parts, service or accessories you may require.

Your dealer is committed to your satisfaction. He has taken training to perform the initial set-up and inspection of your snowmobile as well as completed the final adjustment required to suit your specific weight and riding environment before you took possession.

At delivery, you were informed of the warranty coverage and signed the *PREDELIVERY CHECK LIST* to ensure your new vehicle was prepared to your entire satisfaction.

## Know Before you Go

To learn how to reduce the risk for you, your passenger or bystanders being hurt or killed, read the following sections before you operate the vehicle:

- SAFETY INFORMATION
- VEHICLE INFORMATION.


We highly recommend that you take a safety riding course. Please check with your dealer or local authorities for availability in your area.

## Safety Messages

The types of safety messages, what they look like and how they are used in this guide are explained as follows:

### **WARNING**

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

 **CAUTION** Indicates a hazard situation which, if not avoided, could result in minor or moderate injury.

**NOTICE** Indicates an instruction which, if not followed, could severely damage vehicle components or other property.

## About this Operator's Guide

This Operator's Guide has been prepared to acquaint the owner/operator and passenger with this snowmobile and its various controls, safe riding and maintenance instructions.

This guide is indispensable for the proper use of the product and should be kept with this snowmobile at all times, so you can refer to it.

Note that this guide is available in several languages. In the event of any discrepancy, the English version shall prevail.

If you want to view and/or print an extra copy of your Operator's Guide, simply visit the following website [www.operatorsguide.brp.com](http://www.operatorsguide.brp.com).

The informations contained in this document are correct at the time of publication. BRP, however, maintains a policy of continuous improvement of its products without imposing upon itself any obligation to install them on products previously manufactured. Due to late changes, some differences between the manufactured product and the descriptions and/or specifications in this guide may occur. BRP reserves the right at any time to discontinue or change specifications, designs, features, models or equipment without incurring any obligation upon itself.

This Operator's Guide and the *SAFETY DVD* should remain with the vehicle when it's sold.

---

# TABLE OF CONTENTS

<b>FOREWORD</b> .....	<b>1</b>
Know Before you Go .....	1
Safety Messages.....	1
About this Operator's Guide .....	1

## ***SAFETY INFORMATION***

<b>GENERAL PRECAUTIONS</b> .....	<b>8</b>
Avoid Carbon Monoxide Poisoning .....	8
Avoid Gasoline Fires and Other Hazards .....	8
Avoid Burns from Hot Parts .....	8
Accessories and Modifications .....	8
<b>SPECIAL SAFETY MESSAGES</b> .....	<b>9</b>
<b>RIDING THE VEHICLE</b> .....	<b>12</b>
Pre-Ride Inspection .....	12
How to Ride .....	14
Carrying a Passenger .....	15
Terrain/Riding Variations .....	16
Environment.....	20
<b>TRACTION ENHANCING PRODUCTS</b> .....	<b>22</b>
Manoeuvrability .....	22
Acceleration .....	23
Braking .....	23
Important Safety Rules .....	23
Effects of Having a Studded Track on the Life of the Snowmobile .....	24
Installation of Studs on BRP Approved Tracks .....	24
Maintenance/Replacement .....	25
<b>HANG TAG</b> .....	<b>26</b>
<b>IMPORTANT ON-PRODUCT LABELS</b> .....	<b>27</b>

## ***VEHICLE INFORMATION***

<b>CONTROLS/INSTRUMENTS/EQUIPMENT</b> .....	<b>32</b>
1) Handlebar .....	33
2) Throttle Lever.....	33
3) Brake Lever .....	33
4) Parking Brake Lever .....	34
5) DESS Post .....	34
6) Engine Stop Switch .....	35
7) Choke Lever .....	36
8) Multifunction Switch.....	36
9) Rewind Starter Handle .....	38
10) Heated Carburetor Valve (500SS/800R) .....	38
11) Adjustable Mirrors .....	39
12) Seat Latch .....	39

<b>CONTROLS/INSTRUMENTS/EQUIPMENT (cont'd)</b>	
13) Tool Kit .....	40
14) Grab Handle/Bumper .....	40
15) Gauge .....	41
16) Holding Strap .....	53
17) Storage Compartment .....	54
18) Rear Rack .....	54
19) Integrated Bag .....	54
20) 1+1 Seat .....	54
21) Rear Grab Handles .....	56
22) Rear Passenger Heating Grip Switch .....	56
23) Electric Visor Jack Connector .....	56
24) 12-Volt Power Outlet .....	56
25) C-Type Hitch .....	56
<b>FUEL AND OIL .....</b>	<b>58</b>
Recommended Fuel .....	58
Fueling Procedure .....	58
Recommended Oil .....	59
Injection Oil Level .....	59
<b>OPERATING INSTRUCTIONS .....</b>	<b>60</b>
Operating During Break-In .....	60
Engine Starting Procedure (500SS/800R) .....	60
Engine Starting Procedure (600 HO E-TEC) .....	61
Emergency Starting .....	61
Riding Conditions and your Snowmobile .....	62
Vehicle Warm-Up .....	63
Reverse (RER) .....	64
Shutting Off the Engine .....	64
Towing an Accessory .....	64
Towing Another Snowmobile .....	64
Post-Operation Care .....	65
<b>TUNE YOUR RIDE .....</b>	<b>66</b>
Rear Suspension Adjustment .....	66
Front Suspension Adjustments .....	70
Vehicle Behavior Related to Suspension Adjustment .....	72
<b>VEHICLE TRANSPORTATION .....</b>	<b>73</b>
<b>MAINTENANCE INFORMATION</b>	
<b>MAINTENANCE SCHEDULE .....</b>	<b>76</b>
<b>10-HOUR INSPECTION .....</b>	<b>80</b>
<b>MAINTENANCE PROCEDURES .....</b>	<b>81</b>
Air Intake Silencer Prefilter .....	81
Engine Coolant .....	81
Exhaust System .....	81
Spark Plugs (500SS/800R) .....	82

<b>MAINTENANCE PROCEDURES (cont'd)</b>	
Spark Plugs (600 HO E-TEC) .....	82
Engine Stopper .....	82
Brake Fluid .....	83
Chaincase Oil .....	83
Drive Belt Guard .....	84
Drive Belt .....	85
Drive Pulley .....	92
Track .....	93
Suspension .....	96
Skis .....	97
Fuses .....	97
Lights .....	99
Body .....	100
<b>STORAGE AND PRESEASON PREPARATION .....</b>	<b>102</b>
Storage .....	102
Preseason Preparation .....	103

**TECHNICAL INFORMATION**

<b>VEHICLE IDENTIFICATION .....</b>	<b>106</b>
Vehicle Description Decal .....	106
Serial Numbers .....	106
<b>DECLARATION CE OF CONFORMITY .....</b>	<b>107</b>
<b>EPA CERTIFIED ENGINES .....</b>	<b>108</b>
Engine Emissions Information .....	108
<b>SPECIFICATIONS .....</b>	<b>109</b>

**TROUBLESHOOTING**

<b>TECHNICAL GUIDELINES (500SS AND 800R) .....</b>	<b>122</b>
<b>TECHNICAL GUIDELINES (600 HO E-TEC) .....</b>	<b>125</b>
<b>MONITORING SYSTEM .....</b>	<b>127</b>
Pilot Lamps, Messages and Beeper Codes .....	127
How to Read Fault Codes .....	129

**WARRANTY**

<b>BRP LIMITED WARRANTY USA AND CANADA: 2009 SKI-DOO® SNOWMOBILES .....</b>	<b>132</b>
<b>BRP INTERNATIONAL LIMITED WARRANTY: 2009 SKI-DOO® SNOWMOBILES .....</b>	<b>137</b>

**BRP LIMITED WARRANTY FOR THE EUROPEAN ECONOMIC AREA: 2009 SKI-  
DOO® SNOWMOBILES ..... 141**

**PRIVACY OBLIGATION/DISCLAIMER ..... 145**

**CHANGE OF ADDRESS/OWNERSHIP..... 146**





# ***SAFETY INFORMATION***

---

# GENERAL PRECAUTIONS

## **Avoid Carbon Monoxide Poisoning**

All engine exhaust contains carbon monoxide, a deadly gas. Breathing carbon monoxide can cause headaches, dizziness, drowsiness, nausea, confusion and eventually death.

Carbon monoxide is a colorless, odorless, tasteless gas that may be present even if you do not see or smell any engine exhaust. Deadly levels of carbon monoxide can collect rapidly, and you can quickly be overcome and unable to save yourself. Also, deadly levels of carbon monoxide can linger for hours or days in enclosed or poorly ventilated areas. If you experience any symptoms of carbon monoxide poisoning, leave the area immediately, get fresh air and seek medical treatment.

To prevent serious injury or death from carbon monoxide:

- Never run the vehicle in poorly ventilated or partially enclosed areas such as garages, carports or barns. Even if you try to ventilate engine exhaust with fans or open windows and doors, carbon monoxide can rapidly reach dangerous levels.
- Never run the vehicle outdoors where engine exhaust can be drawn into a building through openings such as windows and doors.

## **Avoid Gasoline Fires and Other Hazards**

Gasoline is extremely flammable and highly explosive. Fuel vapors can spread and be ignited by a spark or flame many feet away from the engine. To reduce the risk of fire or explosion, follow these instructions:

- Refuel outdoors in a well ventilated area away from flames, sparks, anyone smoking and other sources of ignition.
- Never add fuel with engine running.

- Never top off the fuel tank. Leave some room for the fuel to expand with temperature changes.
- Wipe up any spilled fuel.
- Never start or operate the engine with the fuel cap removed.
- Use only an approved red gasoline container to store fuel.

Gasoline is poisonous and can cause injury or death.

- Never siphon gasoline by mouth.
- If you swallow gasoline, get any in your eye or inhale gasoline vapor, see your doctor immediately.

If gasoline spills on you, wash with soap and water and change your clothes.

## **Avoid Burns from Hot Parts**

The exhaust system and engine become hot during operation. Avoid contact during and shortly after operation to avoid burns.

## **Accessories and Modifications**

Do not make unauthorized modifications, or use attachments or accessories that are not approved by BRP. Since these changes have not been tested by BRP, they may increase the risk of crashes or injuries, and they can make the vehicle illegal.

See your authorized SKI-DOO dealer for available accessories for your vehicle.

---

## SPECIAL SAFETY MESSAGES

**SEVERE INJURY OR DEATH** can result if you do not follow these instructions:

- ▲ Everyone is a beginner the first time he sits behind the controls of a snowmobile regardless of previous experience in driving an automobile, a motorcycle or a motorboat. The safe use of your snowmobile is dependent on many conditions such as visibility, speed, weather, environment, traffic, vehicle condition and the condition of the driver.
- ▲ Basic training is required for the safe operation of any snowmobile. Study your Operator's Guide paying particular attention to cautions and warnings. Join your local snowmobile club: its social activities and trail systems are planned for both fun and safety. Obtain basic instructions from your snowmobile dealer, friend, fellow club member or enroll in your state or provincial safety training program.
- ▲ Always show a new operator how to start and stop the vehicle. Indicate the correct riding positions and, above all else, only allow him to operate the snowmobile in a restricted flat area — at least until he is completely familiar with its operation. If there is a local snowmobile operator's training course existing, have him enroll.
- ▲ The performance of some snowmobiles may significantly exceed that of other snowmobiles you have operated. Therefore, use by novice or inexperienced operators is not recommended.
- ▲ Snowmobiles are used in many areas and in many snow conditions. Not all models perform the same in similar conditions. Always consult your snowmobile dealer when selecting the snowmobile model for your particular needs and uses.
- ▲ Injury or death may result to the snowmobile operator, passenger or bystander if the snowmobile is used in risky conditions which are beyond the driver's, passenger's or snowmobile's capabilities or intended use.
- ▲ BRP recommends the operator has at least 16 years old of age.
- ▲ Know your local laws. Federal, state, provincial and local government agencies have enacted laws and regulations pertaining to the safe use and operation of snowmobiles. It is your responsibility as a snowmobiler to learn and obey these laws and regulations. Respect and observance will result in safer snowmobiling for all. Be aware of the liability property damages and insurance laws regarding your equipment.
- ▲ Speeding can be fatal. In many cases, you cannot react or respond quickly enough to the unexpected. Always ride at a speed which is suitable to the trail, weather conditions and your own ability. Know your local rules. Speed limit may be in effect and meant to be observed.
- ▲ Always keep right hand side of the trail.
- ▲ Always keep a safe distance from other snowmobiles and bystanders.
- ▲ Remember, promotional material may show risky maneuvers performed by professional riders under ideal and/or controlled conditions. You should never attempt any such risky maneuvers if they are beyond your level of riding ability.
- ▲ Never ride under the influence of drugs or alcohol or if you feel tired or ill. Operate your snowmobile prudently.
- ▲ Your snowmobile is not designed to be operated on public streets, roads or highways.

- ⚠ Snowmobiling at night can be a delightful experience but because of reduced visibility, be extra cautious. Avoid unfamiliar terrain and be sure your lights are working. Always carry a flashlight and spare light bulbs.
- ⚠ Never remove any original equipment from your snowmobile. Each vehicle has many built in safety features. Such features include various guards and consoles, plus reflective materials and warning labels.
- ⚠ Nature is wonderful but don't let it distract your attention from driving. If you want to truly appreciate winter's scenery, stop your snowmobile on the side of the trail so that **you** don't become a hazard to others.
- ⚠ Fences represent a very serious threat for both you and your snowmobile. Give a wide berth to telephone poles or posts.
- ⚠ Hidden wires unseen from a distance can cause serious accidents.
- ⚠ Always wear an approved safety helmet, eye protection and a face shield. This also applies to your passenger.
- ⚠ Be aware of inherent risks associated with riding off trails, such as avalanche and other natural or man made hazards or obstacles.
- ⚠ Avoid road traveling. If you must do so, and it is permitted, reduce speed. The snowmobile is not designed to operate or turn on paving. When crossing a road, make a full stop, then look carefully in both directions before crossing at a 90° angle. Be wary of parked vehicles.
- ⚠ Tailgating another snowmobile should be avoided. If the snowmobile in front of you slows for any reason, its driver and passenger could be harmed through your neglect. Maintain a safe stopping distance between you and the snowmobile in front of you. Depending on the terrain condition, stopping may require a little more space than you think. Play it safe. Be prepared to use evasive driving.
- ⚠ Venturing out alone with your snowmobile could also be hazardous. You could run out of fuel, have an accident, or damage your snowmobile. Remember, your snowmobile is capable of traveling further in half an hour than you may be able to walk in a day. Use the "buddy system". Always ride with a friend or member of your snowmobile club. Even then, tell someone where you are going and the approximate time you plan to return.
- ⚠ Meadows sometimes have low areas where water accumulate and freezes over in winter. This ice is usually glare ice. Attempting to turn or brake on this surface could cause your vehicle to spin out of control. Never brake or attempt speeding or turning on glare ice. If you do happen to travel over such a condition, reduce speed by carefully releasing the throttle.
- ⚠ Never "jump" with your snowmobile. This should be left to professional stunt men. Don't show off. Be responsible.
- ⚠ While on safari, do not "gun" the throttle. Snow and ice can be thrown back into the path of a following snowmobile. In addition, when "gunning" the throttle, the vehicle digs into and leaves an irregular snow surface for others.
- ⚠ Safaris are both fun and enjoyable but don't show off or overtake others in the group. A less experienced operator might try to do the same as you and fail. When riding with others, limit your abilities to the experience of others.
- ⚠ Always make a pre-ride inspection BEFORE you start the engine.
- ⚠ In an emergency, the snowmobile engine can be stopped by pressing down on the engine stop switch or by pulling the tether cord cap (DESS™ key).

- ⚠ Throttle mechanism should be checked for free movement and return to idle position before starting engine.
- ⚠ Always engage parking brake when vehicle is not in use.
- ⚠ Never run the engine in a non-ventilated area and/or if vehicle is left unattended.
- ⚠ Always engage parking brake before starting the engine.
- ⚠ Never operate the engine without belt guard and brake disk guard securely installed or, with hood or side panels opened or removed. Never run the engine without drive belt installed. Running an unloaded engine such as without drive belt or with track raised, can be dangerous.
- ⚠ **Electric start models only:** Never charge or boost a battery while installed on snowmobile.
- ⚠ E-TEC engines: Never attempt any fuel system or electrical system maintenance or repair. Any maintenance or repair of these systems must be performed by an authorized SKI-DOO dealer.
- ⚠ Ensure the path behind is clear of obstacles or bystanders before proceeding in reverse.
- ⚠ Always remove the tether cord cap (DESS key) when vehicle is not in operation in order to prevent accidental engine starting, to avoid unauthorized use by children or others or theft.
- ⚠ Raising the rear of your snowmobile while the engine is running could cause snow, ice or debris to be thrown back at an observer. Never raise the rear of the vehicle while the engine is running. To clear or inspect the track, stop the engine, tilt the vehicle on its side and remove blockage with a piece of wood or branch. Never allow anyone near a rotating snowmobile track.
- ⚠ Do not stud the track unless it has been approved for studs. At speed, a studded track that has not been approved for studs could tear and separate from vehicle posing a risk of severe injury or death. See an authorized SKI-DOO dealer for current specific studding availability and applications.
- ⚠ You may stud the track on this vehicle model. However, you **MUST** only use the BRP approved type stud for use on Ski-Doo snowmobiles. **DO NOT EVER** use conventional studs because the track thickness is thinner than our standard tracks. The stud could tear off of track and separate from vehicle posing a potential risk of severe injury or death.
- ⚠ Never ride as a passenger unless the snowmobile is equipped with a passenger seat, and sit only on the designated passenger seat.
- ⚠ Always wear a DOT approved helmet and follow the same dressing guidelines as those recommended for the operator and described in this guide.
- ⚠ Make sure that you are able to achieve a stable stance, both feet resting positively on the footboards of footrests with good grip, and that you are able to hold on firmly to the handholds.
- ⚠ Once underway, if you feel uncomfortable or insecure for any reason, don't wait, tell the driver to slow down or stop.

# RIDING THE VEHICLE

Each operator has a responsibility to ensure the safety of other recreationists or bystanders.

You are responsible for proper operation of your vehicle as well as training those whom you allow to ride or drive. There may be noticeable handling and performance differences from one snowmobile to the other.

A snowmobile is relatively simple to operate but like any other vehicle or mechanical equipment, it can be hazardous if you or a passenger are reckless, thoughtless or inattentive. We encourage you to have an Annual Safety Inspection of your snowmobile. Please contact an authorized SKI-DOO dealer for further details. Finally, we urge you to visit an authorized SKI-DOO dealer periodically for regular and safety maintenance, as well as snowmobile accessories you may require.

Before venturing on the trails, operate the snowmobile in a restricted flat area until you are completely familiar with its operation and feel comfortable that you can safely tackle a more demanding task. Have an enjoyable and safe ride.

## Pre-Ride Inspection

### WARNING

The pre-operation check is very important prior to operating the vehicle. Always check the proper operation of critical controls, safety features and mechanical components before starting. If not done as specified here, severe injury or death might occur.

1. Be warmly dressed with clothing designed for snowmobiling.
2. Remove snow and ice from body including seat, footrests, controls and instruments.

3. Verify that skis and steering operate freely. Check corresponding action of skis versus handlebar.
4. Check fuel and oil for levels and leaks. Replenish as necessary and see an authorized SKI-DOO dealer in case of any leaks.
5. Verify that air silencer prefilter is free of snow.
6. All storage compartments must be properly latched and they must not contain any heavy or breakable objects. Hood and side panels must be also properly latched.

### WARNING

Always use a wide base snowmobile mechanical stand to properly support vehicle during any track verification. Never take place in front or behind the snowmobile. Slowly accelerate engine in order to rotate track at very low speed when it is not on ground.

7. Make certain your snowmobile is pointed away from people or objects before you start it. No one is to be standing in front of or in back of the snowmobile.
8. Activate the throttle control lever several times to check that it operates easily and smoothly. It must return to idle position when released.
9. Verify that track and idler wheels are free to turn and not frozen.
10. Activate the brake control lever and make sure the brake fully applies before the brake control lever touches the handlebar grip. It must fully return when released.
11. Check the parking device. Apply parking brake and check if it operates properly.

12. Lights — The headlights, taillight and brake light are standard equipment. Be sure lights are clear of dirt, slush or snow and are in good working order or condition.
13. Check operation of tether cord cap (DESS key), engine stop switches, headlight switch (HI-LO), taillight, brake light and pilot lamps.


**WARNING**

All adjustable features should be positioned at optimal setting. Securely tighten all adjustment locks.

PRE-RIDE CHECK LIST		
ITEM	OPERATION	✓
Clothing	Be warmly dressed with clothing designed for snowmobiling.	
Body including seat, footrests, lights, controls and instruments	Check that there is no snow or ice.	
Skis and steering	Check for free movement and proper action.	
Fuel and oil	Check for proper level and leaks.	
Air silencer prefilter	Check that there is no snow or ice.	
Storage compartment	Check for proper latching and no heavy or breakable objects.	
Adjustable features	Check for optimal adjustment and securely tightened adjustment locks.	
Vehicle vicinity	Snowmobile must be pointed away from people or objects. No one is to be standing in front of or in back of the snowmobile.	
Throttle lever	Check proper action.	
Track and idler wheels	Check for free movement.	
Brake lever	Check proper action.	
Parking device	Check proper action.	
Switches and lights	Check proper action. Tether cord must be attached to driver clothing eyelet.	

## How to Ride

### Riding Gear

Proper snowmobile clothing should be worn. It should be comfortable and not too tight. Always check the weather forecast before going on a ride. Dress for the coldest weather expected. Thermal underwear next to the skin also provides a good insulation.

DOT approved helmets are recommended at all times. They provide both warmth and reduce injury. A stocking type cap, balaclava and face mask should always be carried or worn. Goggles or a face shield that attach to the helmet are indispensable.

Hands should be protected by a pair of snowmobile gloves or mitts which have sufficient insulation and allow use of thumbs and fingers for operation of controls.

Rubber bottom boots with either a nylon or a leather top, with removable felt liners are best suited for snowmobiling.

You should keep yourself as dry as possible when snowmobiling. When you come indoors, take your snowmobile suit and boots off and make certain they dry properly.

Do not wear long scarfs and loose apparel that could get caught in moving parts.

### What to Bring

Every snowmobiler should carry at least the following basic parts and tools that can help him and others in an emergency:

- This Operator's Guide
- Spare spark plugs and wrench
- Friction tape
- Spare drive belt
- Spare starter rope
- Spare light bulbs

- Tool kit (including at least pliers, screwdriver, adjustable wrench)
- Knife
- Flashlight.

Include other items depending on the length and time of your ride.

### Riding Position

Your riding position and balance are the two basic principles of making your snowmobile go where you want it to. When turning on the side of a hill, you and your passenger must be ready to shift body weight to help it turn in the desired direction. Driver and passenger(s) must never attempt this maneuvering by placing feet outside of the vehicle. Experience will teach you how much lean to put into turns at different speeds and how much you will have to lean into a slope to maintain proper balance.

Generally, the riding position for best balance and control is sitting. However, the posting, kneeling or standing positions are also used under certain conditions.

The novice driver should become familiar with the snowmobile through practice on a level area at slow speeds before venturing afield.

### WARNING

**Do not attempt any maneuvers if they are beyond your abilities.**

### Sitting

Feet on the running boards, body mid-way back on seat is an ideal position when operating the snowmobile over familiar, smooth terrain. Knees and hips should remain flexible to absorb shocks.





### Posting

A semi-sitting position with the body off the seat and the feet under the body in a sort of squatting posture, thus allowing the legs to absorb the shocks when traveling over uneven terrain. Avoid abrupt stops.



### Kneeling

This position is achieved by placing one foot firmly on the running board and the opposite knee on the seat. Avoid abrupt stops.



### Standing

Place both feet on the running boards. Knees should be flexed to absorb the shock from surface bumps. This is an effective position to see better and to shift weight as conditions dictate. Avoid abrupt stop.



### Carrying a Passenger

Certain snowmobiles are designed for an operator only, others can allow one passenger only, and others can allow up to two passengers. Refer to the indications on the vehicles to know if any particular snowmobile can accommodate passengers or not, and if so, how many. Always respect those indications. Overloading is dangerous because snowmobiles are not designed for it.

Even when passengers are allowed, you must make sure that the persons who would like to become passengers are physically fit for snowmobiling.

### **⚠ WARNING**

Any passenger must be able to firmly lay his feet on the footrests and keep his hands on the grab handles or seat strap at all times when seated. Respecting those physical criteria is important to ensure that the passenger is stable and to reduce the risks of ejection.

On snowmobiles allowing two passengers, if you have an adult and a child for passenger, BRP recommends that the child sits in the center location. This allows an adult sitting in the rear seat to keep a visual contact with the child and hold him if necessary. In addition, the child is best protected against the wind and cold temperature if seated in the center location.

Each operator has a responsibility to ensure the safety of his passengers and should inform them of snowmobiling basics.

### WARNING

- Passengers must only sit on designated passenger seats. Never allow anyone to sit between the handlebar and the operator.
- Each passenger seat must have a strap or grab handles and meet SSCC standards.
- Passengers and operators must always wear DOT approved helmets and warm clothing appropriate for snowmobiling. Make sure that no skin is exposed.
- Once underway, if a passenger feels uncomfortable or insecure for any reason, he must not wait, and tell the driver to slowdown or stop.

Riding with passengers on board is different than riding alone. The operator has the benefit of knowing what will be the next maneuver and is able to prepare himself accordingly. The operator also benefits from the support of his grip on the handlebar. In contrast, the passengers have to rely on the operator's careful and safe operation of the vehicle. In addition, "body english" is limited with passengers, and the operator can sometimes see more of the trail ahead than the passengers. Therefore, smooth starting and stopping are required with passengers, and

the operator must slow down. The operator must also warn passengers of side hills, bumps, branches, etc. An unforeseen bump can leave you passenger-less. Remind your passengers to lean into the turn with you, without causing the vehicle to topple. Be extremely careful, go more slowly and check the passengers frequently.

### WARNING

**When riding with a passenger:**

- Braking ability and steering control are reduced. Decrease speed and allow extra space to maneuver.
- Adjust suspension according to weight.

For complete information on how to adjust the suspension, please refer to the *TUNE YOUR RIDE* section.

Use extra caution and go even more slowly with young passengers. Check frequently to make certain the child has a firm grip and is properly positioned with his feet on the running boards.

## Terrain/Riding Variations

### Groomed Trail

On a maintained trail, sitting is the most preferred riding position. Do not race and, above all, keep to the right hand side of the trail. Be prepared for the unexpected. Observe all trail signs. Do not zigzag from one side of the trail to the other.

### Ungroomed Trail

Unless there has been a fresh snowfall you can expect "washboard" and snowdrift conditions. Taken at excessive speeds, such conditions can be physically harmful. Slow down. Hold on the handlebar and assume a posting position. Feet should be under the body assuming a crouched position to absorb any jarring effect. On longer

stretches of “washboard” trails, the kneeling position of one knee on the seat can be adopted. This provides a certain amount of comfort, while at the same time keeps the body loose and capable of vehicle control. Beware of hidden rocks or tree stumps partially hidden by a recent snowfall.

### **Deep Snow**

In deep “powder” snow, your vehicle could begin to “bog” down. If this occurs, turn in as wide an arc as possible and look for a firmer base. If you do get “bogged”, and it happens to everyone, do not spin your track as this makes the vehicle sink deeper. Instead, turn the engine off, get off and move the back of the vehicle onto new snow. Then tramp a clear path ahead of the vehicle. A few feet will generally suffice. Restart the engine. Assume the standing position and rock the vehicle gently as you steadily and slowly apply the throttle. Depending on whether the front or rear end of the vehicle is sinking, your feet should be placed on the opposing end of the running boards. Never place foreign material beneath the track for support. Do not allow anyone to stand in front of, or to the rear of, the snowmobile with the engine running. Stay away from the track. Personal injury will result if contact is made with the revolving track.

### **Frozen Water**

Traveling frozen lakes and rivers can be fatal. Avoid waterways. If you are in an unfamiliar area, ask the local authorities or residents about the ice condition, inlets, outlets, springs, fast moving currents or other hazards. Never attempt to operate your snowmobile on ice that may be too weak to support you and the vehicle. Operating a snowmobile on ice or icy surfaces can be very dangerous if you do not observe certain precautions. The very nature of ice is foreign to good control of a snowmobile or any vehicle.

Traction for starting, turning or stopping is much less than that on snow. Thus, these distances can be multiplied manyfold. Steering is minimal, and uncontrolled spins are an ever present danger. When operating on ice, drive slowly with caution. Allow yourself plenty of room for stopping and turning. This is especially true at night.

### **Hard Packed Snow**

Don't underestimate hard packed snow. It can be difficult to negotiate as both skis and track do not have as much traction. Best advice is to slow down and avoid rapid acceleration, turning or braking.

### **Uphill**

There are two types of hills you can encounter — the open hill on which there are few trees, cliffs or other obstacles, and a hill that can only be climbed directly. On an open hill, the approach is to climb it by side hilling or slaloming. Approach at an angle. Adopt a kneeling position. Keep your weight on the uphill side at all times. Maintain a steady, safe speed. Continue as far as you can in this direction, then switch to an opposite hill angle and riding position.

A direct climb could present problems. Choose the standing position, accelerate before you start the climb and then reduce throttle pressure to prevent track slippage.

In either case, vehicle speed should be as fast as the incline demands. Always slow down as you reach the crest. If you cannot proceed further, don't spin your track. Turn the engine off, free the skis by pulling them out and downhill, place the rear of the snowmobile uphill restart the engine and ease it out with slow even throttle pressure. Position yourself to avoid tipping over, then descend.

## **Downhill**

Downhill driving requires that you have full control of your vehicle at all times. On steeper hills, keep your center of gravity low and both hands on the handlebar. Maintain slight throttle pressure and allow the machine to run downhill with the engine operating. If a higher than safe speed is reached, slow down by braking but apply the brake with frequent light pressure. Never jam the brake and lock the track.

## **Side Hill**

When crossing a side hill or traversing up or downhill, certain procedures must be followed. All riders should lean towards the slope as required for stability. The preferred operating positions are the kneeling position, with the knee of the down hill leg on the seat and the foot of the uphill leg on the running board, or the posting position. Be prepared to shift your weight quickly as needed. Side hills and steep slopes are not recommended for a beginner or a novice snowmobiler.

## **Slush**

Slush should be avoided at all times. Always check for slush before starting across any lake or river. If dark spots appear in your tracks, get off the ice immediately. Ice and water can be thrown rearward into the path of a following snowmobile. Getting a vehicle out of a slush area is strenuous and in some cases, impossible.

## **Fog or Whiteouts**

On land or water, fog or visibility-limiting snow can form. If you have to proceed into the fog or heavy snow, do so slowly with your lights on and watch intently for hazards. If you are not sure of your way, do not proceed. Keep a safe distance behind other snowmobilers to improve visibility and reaction time.

## **Unfamiliar Territory**

Whenever you enter an area that is new to you, drive with extreme caution. Go slow enough to recognize potential hazards such as fences or fence posts, brooks crossing your path, rocks, sudden dips, guy wires and countless other obstacles which could result in a termination of your snowmobile ride. Even when following existing tracks, be cautious. Travel at a speed so you can see what is around the next bend or over the top of the hill.

## **Bright Sunshine**

Bright sunny days can considerably reduce your vision. The glare from sun and snow may blind you to the extent that you cannot easily distinguish ravines, ditches or other obstacles. Goggles with colored lenses should always be worn under these conditions.

## **Unseen Obstruction**

There may be obstructions hidden beneath the snow. Driving off established trails and in the woods requires reduced speed and increased vigilance. Driving too fast in an area can make even minor obstacles very hazardous. Even hitting a small rock or stump could throw your snowmobile out of control and cause injury to its riders. Stay on established trails to reduce your exposure to hazards. Be safe, slow down and enjoy the scenery.

## **Hidden Wires**

Always be on the lookout for hidden wires, especially in areas that may have been farmed at one time or another. Too many accidents have been caused by running into wires in the fields, guy wires next to poles and roads, and into chains and wires used as road closures. Slow speeds are a must.

## Obstacles and Jumping

Unplanned jumps of snowdrifts, snowplow ridges, culverts or indistinguishable objects can be dangerous. You can avoid them by wearing the proper color lenses or face shields and by operating at a lower speed.

Jumping a snowmobile is an unsafe and dangerous practice. However, if the trail does suddenly drop away from you, crouch (stand) towards the rear of the vehicle and keep the skis up and straight ahead. Apply partial throttle and brace yourself for the impact. Knees must be flexed to act as shock absorbers.

## Turning

Depending on terrain conditions, there are two preferred ways to turn or corner a snowmobile. For most snow surfaces, "body english" is the key to turning. Leaning towards the inside of the turn and positioning body weight on the inside foot will create a "banking" condition beneath the track. By adopting this position and positioning yourself as far forward as possible, weight will be transferred to the inside ski.

On occasion, you will find that the only way to turn the vehicle about in deep snow is to pull the snowmobile around. Do not over-exert yourself. Get assistance. Remember to always lift using your legs as opposed to your back.



nmc2008-003-005

## Road Crossing

In some cases, you will be approaching the road from a ditch or snowbank. Choose a place where you know you can climb without difficulty. Use the standing position and proceed with only as much speed needed to crest the bank. Stop completely at the top of the bank and wait for all traffic to clear. Judge the drop to the roadway. Cross the road at a 90° angle. If you encounter another snowbank on the opposite side, position your feet near the rear of the vehicle. Remember, your snowmobile is not designed to operate on bare pavement and steering on this type of surface is more difficult.

## Railroad Crossing

Never ride on railroad tracks. It is illegal. Railroad tracks and railroad rights-of-way are private property. A snowmobile is no match for a train. When crossing a railroad track, stop, look and listen.

## Night Rides

The amount of natural and artificial light at a given time can effect your ability to see or to be seen. Nighttime snowmobiling is delightful. It can be a unique experience if you acknowledge your reduced visibility. Before you start, make certain your lights are clean and work properly. Drive at speeds that will allow you to stop in time when you see an unknown or dangerous object ahead. Stay on established trails and never operate in unfamiliar territory. Avoid rivers and lakes. Guy wires, barbed wire fences, cabled road entrances and other objects such as tree limbs are difficult to see at night. Never drive alone. Always carry a flashlight. Keep away from residential areas and respect the right of others to sleep.

## Safari Riding

Before starting out, designate a "trail boss" to lead the party and another person to follow-up at the end of the party. Ensure that all members of the party are aware of the proposed route and destination. Make certain that you are carrying all necessary tools and equipment and that you have sufficient fuel to complete the trip. Never overtake the trail boss or, for that matter, any other snowmobile. Use down-the-line hand signals to indicate hazards or intent of direction change. Assist others whenever necessary.

It is always IMPORTANT to keep a safe distance between each snowmobile. Always maintain a safe interval and allow sufficient stopping distance. Don't be a tailgater. Know the position of the machine ahead.

## Signals

If you intend to stop, raise either hand straight above your head. A left turn is indicated by extending your left hand straight out in the proper direction. For right turns, extend the left arm and raise the hand to a vertical position so it forms a right angle at the elbow. Every snowmobiler should relay any signal to the ones behind.

## Trail Stops

Whenever possible, pull off the trail when you stop. This will reduce the hazard to other snowmobilers using the trail.

## Trails and Signs

Trail signs are used to control, direct or regulate the use of snowmobiles on trails. Become familiar with all signs used in the area where you are snowmobiling.

## Environment

Wildlife compliments your snowmobiling day. Snowmobile tracks provide firm ground over which animals can

travel from area to area. Do not violate this privilege by chasing or harassing wildlife. Fatigue and exhaustion can lead to animal's death. Avoid areas posted for the protection or feeding of wildlife.

If you happen to be fortunate enough to see an animal, stop your snowmobile and observe quietly.

The guidelines that we support are not designed to limit your snowmobiling fun, but to preserve the beautiful freedom that you can experience only on a snowmobile! These guidelines will keep snowmobilers healthy, happy and able to introduce others to what they know and enjoy about their favorite winter pastime. So, the next time you hit the trails on a cool, crisp and clear winter day, we ask you to remember that you are paving the way for the future of our sport. Help us lead it down the right path! From all of us at BRP, thank you for doing your share.

There is nothing more exhilarating than snowmobiling. Venturing onto snowmobile trails that criss-cross wild areas is an exciting and healthy winter sport. However, as the number of people using these recreational parks increases, so does the potential for damage to the environment. Abuse of land, facilities and resources inevitably leads to restrictions and closures of both private and public land.

In essence, the greatest threat to our sport, is all around us. Which leaves us with one logical choice. When we snowmobile, we must always ride responsibly.

The vast majority respect the law and the environment. Each of us must set an example for those who are new to the sport, young and old alike.

It is in every one's best interest to tread lightly into our recreational areas. Because, in the long run, to protect the sport we must preserve the environment.

Recognizing the importance of this issue and the need for snowmobilers to do their share in preserving areas that make it possible to enjoy our sport, BRP has developed the "Light Treading Is Smart Sledding" campaign for snowmobilers.

Light Treading refers to more than the thread of our tracks. It's a statement of concern, respect and willingness to take the lead and take action. It applies to the environment in general, its proper care and maintenance, its natural inhabitants and all enthusiasts and the public at large who enjoy the great outdoors. With this theme, we invite all snowmobilers to remember that respecting the environment is not only critical to the future of our industry but to future generations.

Light Treading in no way suggests you should curb your appetite for snowmobiling fun! It simply means tread with respect!

The fundamental objective of Light Treading is one of respect for where and how you ride a snowmobile. You're a light treader when you follow the principles below.

**Become informed.** Obtain maps, regulations and other information from the Forest Service or from other public land agencies. Learn the rules and follow them and that goes for speed limits, too!

**Avoid** running over young trees, shrubs, and grasses and don't cut wood. On flatlands or areas where trail riding is popular, it's important to ride only where authorized. Remember, there is a link between protecting your environment and your own safety.

**Respect wildlife** and be particularly sensitive of animals that are rearing young or suffering from food shortage. Stress can sap scarce energy reserves. Refrain from riding in areas where only animals are intended to tread!

**Obey** gate closures and regulatory signs and remember, light treaders don't litter!

**Stay out** of wilderness areas. They're closed to all vehicles. Know where the boundaries are.

**Obtain permission** to travel across private land. Respect the rights of landowners and other people's privacy. Remember, snowmobile technology has lowered the noise factor considerably, but you still shouldn't rev your engines where quiet "is the order of the day".

Snowmobilers know all too well the efforts that have been made throughout the sport's history to enjoy access to areas where people can snowmobile safely and responsibly. This effort continues today, as strong as ever.

Respecting the areas where we ride... wherever they may be... is the only way to ensure their future enjoyment. That's one major reason why we know you'll agree that Light Treading is smart sledding! And there are more.

Enjoying the opportunity to see winter and all its natural majestic wonders, is an experience cherished by snowmobilers. Light Treading will preserve this opportunity and will make it possible for us to expose others to the beauty of winter and the unique thrill of our sport! Light Treading will help our sport to grow!

Finally, Light Treading is the sign of a smart snowmobiler. You don't have to leave big tracks or careen through a virgin forest to show you can ride. So whether you're driving a high performance Ski-Doo, a sporty MX Z snowmobile or any other make or model, show you know what you're doing. Show you know how to send snow flying and make tracks with a light touch!

# TRACTION ENHANCING PRODUCTS

**NOTE:** This section is applicable to snowmobiles equipped with a factory installed track that has been approved by BRP for special studs installation.

## **⚠ WARNING**

Never stud a track that has not been approved for studs. Installing studs on an unapproved track could increase the risk of the track tearing or severing, possibly resulting in serious injury or death.

## **⚠ WARNING**

You may stud the track on this vehicle model. However, you **MUST** only use the BRP approved type stud for use on these Ski-Doo snowmobiles. **DO NOT EVER** use conventional studs as the track thickness is thinner than other standard tracks. The stud could tear off of track and separate from vehicle posing a potential risk of severe injury or death. See an authorized SKI-DOO dealer for current specific studding availability and applications.

Using traction enhancing products such as, more aggressive ski carbide runners and/or studs on your snowmobile will change its behavior, particularly in terms of manoeuvrability, acceleration, and braking.

Using traction enhancing products gives a better grip on packed snow and ice, but has no noticeable effect on soft snow. For this reason, driving a snowmobile equipped with traction enhancing products requires a certain adaptation period. If your snowmobile is equipped with traction enhancing products, be sure to take plenty of time to get used to the way it handles when turning, accelerating, and braking.

Also, always check local regulations concerning the use of traction enhancing products on snowmobiles. Always

drive your snowmobile in a responsible manner, respecting the environment and other people's property.

## **Manoeuvrability**


Using traction enhancing products such as, more aggressive ski carbide runners and/or studs makes the snowmobile grip the ground better at both the front and at the rear. The use of carbide runners is therefore required to give the skis a better grip, so that the front and rear of the snowmobile are in balance. While off-the-shelf carbide ski runners are adequate, they don't necessarily give you optimal control, since that depends on your personal preferences, your riding style, and how your suspension is adjusted.

## **⚠ WARNING**

If the front and rear of the snowmobile are out of balance due to an incorrect combination of traction enhancing products, the snowmobile may tend to oversteer or understeer, which could lead to a loss of control.

## **Oversteering**

In certain conditions, using more aggressive ski carbide runners without studs on the rear track could make the snowmobile prone to oversteering, see illustration.




**OVERSTEERING**



## Understeering

In certain conditions, the use of studs on the track could make the snowmobile prone to understeering if the skis are not equipped with more aggressive ski carbide runners, see illustration.




A33A33A

*UNDERSTEERING*

## Controlled Driving

A balanced combination of carbide ski runners and studs on the track ensures adequate control and better handling, see illustration.



A33A34A

*CONTROLLED DRIVING*

## Acceleration

Using studs on the track will allow your sled to accelerate better on packed snow and ice but will have no noticeable effect on soft snow. This can cause sudden variations in traction under certain conditions.

## **⚠ WARNING**

To prevent surprises that could lead to a loss of control of the snowmobile, possibly resulting in serious injury or death:

- Always go easy on the throttle.
- NEVER try to spin the track to make the rear of the snowmobile skid.

This could cause debris or ice to be thrown violently backwards, possibly injuring others nearby or on snowmobiles behind you.

## Braking

As in the case of acceleration, using studs on the track will give you better braking capacity on packed snow or ice but will have no noticeable effect on soft snow. Braking may thus vary suddenly under certain conditions. Be sure to use restraint in braking to keep from blocking the track in order to avoid surprises that could lead to a loss of control.

## Important Safety Rules

### **⚠ WARNING**

To prevent serious injury to individuals near the snowmobile:

- NEVER stand behind or near a moving track.
- Always use a wide-base snowmobile stand with a rear deflector panel.
- When the track is raised off the ground, only run it at the lowest possible speed.

Centrifugal force could cause debris, damaged or loose studs, pieces of torn track, or an entire severed track to be violently thrown backwards out of the tunnel with tremendous force, possibly resulting in the loss of a leg or other serious injury.

## Effects of Having a Studded Track on the Life of the Snowmobile

The use of traction enhancing products can increase the load and the stress on certain snowmobile components, as well as the vibration level. This can cause premature wear on parts such as belts, brake linings, bearings, chain, chaincase sprocket, and on approved studded tracks, shorten track life. Always proceed with a visual inspection of your track before each use. For more information, refer to the *TRACK* section in *MAINTENANCE INFORMATION*.

Studs on the track can also cause serious damage to your snowmobile if it is not equipped with the tunnel protectors designed for your particular model. Damage to the electrical wiring or perforation of the heat exchangers are potential hazards, that could cause the engine to overheat and be severely damaged.

### WARNING

If tunnel protectors are excessively worn or not installed, the gas tank could be punctured, causing a fire.


**NOTICE** Ask your dealer for the appropriate tunnel protectors model and kit number required for your snowmobile.

**NOTE:** Consult the BRP limited warranty to find out what warranty limitations are related to the use of studs.

## Installation of Studs on BRP Approved Tracks

### WARNING

Never stud a track that has not been approved for studs. Approved tracks can be identified by a stud symbol (see illustration below) molded into the track surface. Installing studs on an unapproved track could increase the risk of the track tearing or severing, possibly resulting in serious injury or death.




#### TRACK SYMBOLS

1. Approved
2. NOT Approved

To ensure safe and proper installation, BRP recommends to have the studs installed by your dealer.

- Use only the BRP approved special studs.
- Never use studs that exceed the height of your snowmobile's track profile by more than 9.5 mm (3/8 in).



#### INSTALLATION OF STUDS

1. Stud size
2. Penetration range 6.4 to 9.5 mm (1/4 to 3/8 in)
3. Track lug height
4. Track belt thickness

**⚠ WARNING**

- See an authorized SKI-DOO dealer for current specific stud-  
ding availability and applica-  
tions.
- **DO NOT EVER** use conventional  
stud because, the track thick-  
ness is thinner than our stan-  
dard tracks and the stud could  
tear off of track and separate  
from vehicle posing a potential  
risk of severe injury or death.
- Studs should only be installed  
in the locations indicated by  
molded bulges in the track sur-  
face.
- Never stud a track with a profile  
of 35 mm (1.375 in) or more.
- The number of studs installed  
must always perfectly match  
the pattern of molded bulges in  
the track.
- Always consult the traction  
product manufacturer's instal-  
lation instructions and recom-  
mendations before having your  
dealer install studs and runners.  
It is very important to follow  
the torque specifications for the  
stud bolts.

**INSTALLING AN INCORRECT  
NUMBER OF STUDS OR AN IM-  
PROPER INSTALLATION CAN IN-  
CREASE THE RISK OF THE TRACK  
TEARING OR SEVERING, POSSI-  
BLY RESULTING IN SERIOUS IN-  
JURY OR DEATH.**

- Delamination of the rubber
- Broken rods
- Broken studs (studded tracks)
- Bent studs (studded tracks)
- Missing studs
- Studs that are torn off the track
- Missing track guide(s)
- Also, ensure that studs nut are tight-  
en to the recommended torque.

On approved studded tracks, replace  
broken or damaged studs immediately.  
If your track shows signs of deteriora-  
tion, it must be replaced immediately.  
When in doubt, ask your dealer. Al-  
ways proceed with a visual inspection  
of your track before each use.

**⚠ WARNING**

**Riding with a damaged track or  
studs could lead to loss of control,  
resulting in a risk of serious injury  
or death.**

**Maintenance/Replacement**

PROCEED WITH A VISUAL INSPEC-  
TION OF YOUR TRACK BEFORE  
EACH USE.

Look for any defects, such as:

- Perforations in the track
- Tears in the track (particularly  
around traction holes on studded  
tracks)
- Lugs that are broken or torn off, ex-  
posing portions of rods

# HANG TAG

**VEHICLE ENGINE DESCRIPTION:**  
**XXXXX**

**EPA CERTIFIED**

NER (NORMALIZED EMISSION RATE) =   
ON A 0 TO 10 SCALE, 0 BEING THE CLEANEST

**\*NOT TO BE REMOVED PRIOR TO SALE**



704901107

vmo2006-005-009\_en

**CAUTION**

This snowmobile is calibrated for operating at altitudes between 2000 ft and 8000 ft. Operating above or below these altitudes requires calibration parts and adjustment. For more details, REFER to your Operator's Guide that came with your snowmobile or see your authorized Ski-Doo dealer. FAILURE TO RECALIBRATE MAY CAUSE SERIOUS ENGINE DAMAGE

mmo2008-003-053\_en

**SUMMIT® — NORTH AMERICA**

**CAUTION**

This snowmobile is calibrated for operating at SEA-LEVEL. Operating above 2000 ft requires calibration parts and adjustment. For more details, REFER to your Operator's Guide that came with your snowmobile or see your authorized Ski-Doo dealer. INCORRECT ADJUSTMENTS MAY CAUSE PARTS DAMAGE

mmo2008-003-054\_en

**SUMMIT — EUROPE**

# IMPORTANT ON-PRODUCT LABELS

Safety standards for snowmobiles have been adopted by the Snowmobile Safety and Certification Committee (SSCC) of which BRP is a proud participating member. Assurance that your snowmobile meets these standards is easily checked by locating the Certification Label on a right vertical portion of the vehicle.





This label shows that an independent testing laboratory has verified compliance with the SSCC safety standards.





Other important labels on the vehicle are WARNING or CAUTION labels relating to safety, maintenance and/or snowmobile operation. Ensure all such labeling is retained on the vehicle and its content is followed by vehicle operator and passenger.

If missing or damaged, the decals can be replaced free of charge. See an authorized SKI-DOO dealer.

Please read the following instructions carefully before operating this snowmobile.





**▲ WARNING**

- Read and understand all warning labels and operator's guide before operation. Operator's guide is located in the under seat base. Pull latch located under front tip of seat and slide it to the rear to have access. If guide is missing, ask your dealer for a new one.
- Get familiar with your vehicle. Inexperienced riders may overlook risks and be surprised by vehicle's specific behavior and terrain conditions. Ride slowly.
- Excessive speed and reckless driving can kill! ALWAYS adjust your speed according to snow conditions and circumstances.
- Steering control and braking ability may be reduced on hard-pack snow, ice or roads. Reduce speed & allow more space to stop or turn.
- Respect laws on minimum operator age. Manufacturer recommends a minimum operating age of 16 years old.
- Never open side panels or hood while engine is running or if vehicle is in motion. Ensure to remove DESS key before opening those.

**BEFORE STARTING :**

1. Attach tether cord to your clothing.
2. Check proper operation of the throttle and brake levers each time before starting. They must return to their initial position when released.
3. Apply parking brake.
4. Turn handlebars all the way in both directions to check for interference and insure free operation.

**AFTER STARTING :**

1. Pull-out tether cord to check if engine shuts off.
2. Re-start and push in engine cut-off switch to check if engine shuts off.
3. Disengage parking brake before riding to avoid fading.

mno2009-003-001\_en

**INSTRUCTION 1**

CAUTION	ATTENTION
<ul style="list-style-type: none"> <li>•To comply with noise regulations, this engine is designed to operate with an air intake silencer.</li> <li>•Operation without air intake silencer or with one not properly installed may cause engine damage.</li> </ul>	<ul style="list-style-type: none"> <li>•Le moteur a été conçu pour fonctionner avec ce silencieux d'admission afin de se conformer aux lois et règlements relatifs au bruit.</li> <li>•Son absence ou une mauvaise installation peut endommager le moteur.</li> </ul>

mno2007-009-051

**INSTRUCTION 2**

**▲ WARNING**

This guard must ALWAYS be in place when engine is running. Beware of rotating parts – they could cause injuries or catch your clothing.

**▲ AVERTISSEMENT**

Ce garde-courroie doit TOUJOURS être en place lorsque le moteur fonctionne. Attention aux pièces en rotation – elles peuvent vous blesser ou capter vos vêtements.

516 002 670

A33A2FA

**INSTRUCTION 3**

**▲ WARNING**

Beware of HOT parts!

**▲ AVERTISSEMENT**

Attention aux pièces CHAUDES!

516002664

A33A2GA


**INSTRUCTION 4**




**INSTRUCTION 5**




INSTRUCTION 6



INSTRUCTION 9




INSTRUCTION 7




INSTRUCTION 10



INSTRUCTION 11 - EUROPEAN MODELS



INSTRUCTION 8




INSTRUCTION 12 - RENEGADE/SUMMIT EVEREST EUROPEAN MODELS

**▲ WARNING**

If you stud the track on this vehicle use special BRP approved studs ONLY.  
 Studding this track with conventional studs may cause studs to tear off of track and separate from vehicle posing a potential risk of severe injury or death  
 See the Operator's Guide that came with this vehicle for all details pertaining to track studding

mmo2008-003-052\_en

**INSTRUCTION 13 - MODELS WITH TRACK APPROVED FOR STUDS**

<b>EMISSION CONTROL INFORMATION</b>		
THIS VEHICLE IS CERTIFIED TO OPERATE ON UNLEADED GASOLINE AND MEETS [xxxx] U.S. EPA REGULATIONS FOR SNOWMOBILE SI ENGINES.		
ENGINE FAMILY	XXXX	FAMILLE DE MOTEUR
FEL	XXXX	LIMITE DES ÉMISSIONS DE LA FAMILLE
ENGINE DISPLACEMENT	XXXX	CYLINDRÉE
EXHAUST EMISSION CONTROL SYSTEM	XXXX	SYSTÈME DE CONTRÔLE DES ÉMISSIONS

**RENSEIGNEMENTS SUR LE DISPOSITIF ANTIPOLLUTION**  
 CE VÉHICULE EST CERTIFIÉ POUR FONCTIONNER À L'ESSENCE SANS PLOMB ET IL RÉPOND AUX NORMES [xxxx] DE L'EPA DES É.-U. POUR LES MOTONEIGES À MOTEUR SI.  
 SEE OPERATOR'S GUIDE FOR MAINTENANCE SPECIFICATIONS  
 VOIR GUIDE DU CONDUCTEUR POUR LES SPÉCIFICATIONS D'ENTRETIEN  
 BOMBARDIER RECREATIONAL PRODUCTS INC.

mmo2007-009-070

**INSTRUCTION 14**

**▲ WARNING**

Before riding make sure that every seat is installed properly and securely locked in.

**▲ AVERTISSEMENT**

Avant d'utiliser la motoneige, assurez-vous que tous les sièges soient bien installés et barrés en place.

mmo2009-003-006\_a

**INSTRUCTION 15 - GTX ONLY - NOT SHOWN**

**▲ WARNING**

Always electrically disconnect both fuel injectors prior to testing for ignition spark. Otherwise, fuel vapors may ignite in presence of a spark creating a fire hazard.

mmo2009-003-014\_en


**INSTRUCTION 16 - E-TEC ONLY**




# ***VEHICLE INFORMATION***

# CONTROLS/INSTRUMENTS/EQUIPMENT


NOTE: Some controls/instruments/equipment do not apply or are optional on some models.



TYPICAL




TYPICAL



mmo2009-003-007\_a

TYPICAL



mmo2008-003-069\_c

RENEGADE EUROPEAN MODELS ONLY

## 1) Handlebar


The handlebar controls the steering of the snowmobile. As the handlebar is rotated to right or left, the skis are turned right or left to steer the snowmobile.

### **⚠ WARNING**

Fast reverse while turning, could result in loss of stability and control.

## 2) Throttle Lever

Designed to be thumb activated. When squeezed, it increases the engine speed and engages the transmission. When released, engine speed returns automatically to idle.



mmo2008-008-011\_b

TYPICAL


1. Throttle lever
2. To accelerate
3. To decelerate

### **⚠ WARNING**

Test the throttle lever operation each time before starting the engine. The lever must return to its original position once released. Otherwise, do not start engine.

## 3) Brake Lever


When squeezed, the brake is applied. When released, it automatically returns to its original position. Braking effect is proportional to the pressure applied on the lever and to the type of terrain and its snow coverage.



**TYPICAL**  
 1. Brake lever  
 2. To apply brake

#### 4) Parking Brake Lever

Parking brake should be used whenever snowmobile is parked.



**TYPICAL**  
 1. Parking brake lever

**⚠ WARNING**


Make sure parking brake is fully disengaged before operating the snowmobile. When you ride the vehicle, brake pads that are caused to drag by a continuous pressure on the lever may cause damage to the brake system and cause loss of braking capacity and/or fire.

#### To Engage Mechanism

Squeeze brake lever and maintain while pulling locking lever with a finger. When brake lever is held at halfway the parking brake should be fully applied.

**NOTICE** Parking brake position can vary depending on brake pads wear. Ensure when the parking brake is applied that the vehicle stays securely in place.

**NOTE:** Locking lever can be adjusted in two different positions.




**TYPICAL — ENGAGE MECHANISM**  
 Step 1: Squeeze and maintain brake lever  
 Step 2: Adjust locking lever

1. Position 1
2. Position 2
3. OFF

#### To Release Mechanism

Squeeze brake lever. Locking lever will automatically return to its original position. Always release parking brake before riding.



**TYPICAL — RELEASE MECHANISM**  
 Step 1: Squeeze brake lever

#### 5) DESS Post

The DESS key must be securely snapped on its post to allow vehicle operation.

Pulling the DESS key off its post shuts the engine off.

## **! WARNING**

Always attach the tether cord eye-let to clothing before starting the engine.


### **DESS (Digitally Encoded Security System)**

The tether cord cap (DESS key) is digitally encoded to provide you and your snowmobile with the equivalent security of a conventional lock key and it shuts off the engine preventing snowmobile to runaway if the operator falls off the vehicle accidentally.

The DESS key provided with your snowmobile contains an electronic chip which features a unique permanently memorized digital code. Your authorized SKI-DOO dealer programs this key in the ECM (Engine Control Module) of your snowmobile to allow engine operation above 3000 RPM if and only if this unique code has been read after engine starting.

If another DESS key is installed, the engine will start but will not reach drive pulley engagement speed to move vehicle.

Make sure the DESS key is free of dirt or snow.



#### **DESS KEY**

1. Free of dirt or snow

### **Additional DESS Keys**

The ECM of your snowmobile can be programmed by your authorized SKI-DOO dealer to accept 8 different keys.


We recommend the purchase of additional keys from your authorized SKI-DOO dealer. If you have more than one DESS-equipped SKI-DOO snowmobile, each can be programmed by your authorized SKI-DOO dealer to accept the other vehicles keys.

### **DESS Pilot Lamp Codes**


**NOTE:** 2 short beeps should be heard if a programmed key is correctly snapped on post. Refer to *MONITORING SYSTEMS* for DESS malfunction codes information.

### **6) Engine Stop Switch**

Push-pull type switch. To stop the engine in an emergency, select OFF position (down) and simultaneously apply the brake. To restart, button must be at the ON position (up).



OFF POSITION



ON POSITION

All operators of the snowmobile should familiarize themselves with the function of the engine stop switch by using it several times on first outing and whenever stopping the engine thereafter. This engine stopping procedure will become a reflex and will prepare operators for emergency situations requiring its use.


**⚠ WARNING**

If the switch has been used in an emergency caused by a suspected malfunction, the source of the malfunction should be determined and corrected before restarting engine. See an authorized SKI-DOO dealer for servicing.

**7) Choke Lever**

*500SS and 800R Engines Only*


The choke lever has 3-positions.



- 1. OFF
- 2. Position 2
- 3. Position 3

See proper usage instructions in *OPERATING INSTRUCTIONS* section.

**8) Multifunction Switch**



- TYPICAL**
- 1. Start/Electronic Reverse button
  - 2. Headlights dimmer switch
  - 3. Heating grips
  - 4. Heating throttle lever
  - 5. Mode/set button

**Start/Electronic Reverse Button**

*Electric Start Models*

Press to start engine. Refer to *ENGINE STARTING PROCEDURE* in the *OPERATING INSTRUCTIONS* section.

*All Models*


Press to engage the electronic reverse. Refer to *REVERSE (RER)* in *OPERATING INSTRUCTIONS* section for procedure.

**Headlights Dimmer Switch**

Press to select HI or LOW beam. Lights are automatically ON when the engine is running.

**Heating Grips Switch**


Select the switch position according to the desired heating intensity to keep your hands at a comfortable temperature.

**Models with Analog/Digital Gauge****TYPICAL**

1. Heating grip switch
2. Hot
3. Warm
4. Off

**Models with Multifunction Analog/Digital Gauge**


Depress switch as required to select heating intensity to keep your hands at a comfortable temperature.

**VARIABLE INTENSITY**

1. Heating grip switch
2. Increase heat
3. Decrease heat

The heated grips are enabled at 1900 engine RPM and up.

The heating intensity is displayed via the multifunction display.


**HEATING INTENSITY DISPLAY**

1. Less heat
2. More heat

Heating grips will be in OFF position when there are no bars displayed on the gauge.

**Heating Throttle Lever Switch**


Select the switch position according to the desired heating intensity to keep your thumb at a comfortable temperature.

**Models with Analog/Digital Gauge****TYPICAL**

1. Heated throttle lever switch
2. Hot
3. Warm
4. Off

**Models with Multifunction Analog/Digital Gauge**

Depress switch as required to select heating intensity to keep your thumb at a comfortable temperature.




**VARIABLE INTENSITY**

1. Heated throttle lever switch
2. Increase heat
3. Decrease heat

**NOTE:** The heated throttle lever is enabled at 1900 engine RPM and up.

**NOTE:** The heating intensity is displayed via the multifunction display with the activation of the throttle lever switch. When released, display will return to fuel tank level.



**HEATING INTENSITY DISPLAY**

1. Less heat
2. More heat


Heating throttle lever will be in OFF position when there are no bars displayed on the gauge.

**Mode/Set Button**

**Models with Multifunction Analog/Digital Gauge**

This button can be used instead of the two buttons on top of the analog/digital gauge to facilitate gauge adjustments.

- When pressed upward, it has the same functions as the MODE (M) button.
- When pressed downward, it has the same functions as the SET (S) button.



**MULTIFUNCTION GAUGE**

1. MODE function
2. SET function

**9) Rewind Starter Handle**

*All Models except 600 HO E-TEC with Electric Start*

Auto-rewind type located on right hand side of snowmobile. To engage mechanism, pull handle slowly until a resistance is felt then pull vigorously. Slowly release handle.


**10) Heated Carburetor Valve (500SS/800R)**

The heated carburetor valve should be closed except:

- When riding between - 5°C and 5°C (23°F and 41°F) in a high relative humidity.




- When riding in deep powder snow.
- When following another snowmobile in high snow conditions.



mmo2007-009-018\_a

**TYPICAL — REMOVE BELT GUARD**

1. Carburetor valve



mmo2007-009-039\_a

1. ON position
2. OFF position

**NOTICE** When operating the snowmobile above 5°C (41°F), move the carburetor heating valve to the OFF position.

**11) Adjustable Mirrors**

Each mirror can be adjusted to suit driver's preference.


**⚠ WARNING**

Adjust with vehicle at rest in a safe place.

**12) Seat Latch**

Seat can be removed to have access to the Operator's Guide (located in seat base) or for maintenance purposes.

Seat latch is located at the front of the seat.




mmo2007-009-071\_a

**SEAT BASE**

1. Seat latch
2. Operator's Guide location

**Seat Removal**


To have access to seat latch, gently pull the front of seat.



mmo2007-009-072\_a

1. Seat latch

Pull and hold seat latch, then, pull seat with a rearward movement to remove.




Step 1: Pull and hold seat latch  
Step 2: Pull seat with a rearward movement

### Seat Installation

**NOTICE** Riding the vehicle with any objects between the seat and the fuel tank could damage the fuel tank. NEVER place any objects between seat and fuel tank.

Position seat in place.

Push seat forward until it latch in its position.



Step 1: Position seat in place  
Step 2: Push seat forward until it latch

**NOTE:** A distinctive snap will be felt. Double check that the seat is secure by giving it a tug to confirm proper latching.



SEAT INSTALLED

### **⚠ WARNING**


Make sure seat is securely latched before riding.

### 13) Tool Kit

A tool kit containing tools for basic maintenance is supplied with the vehicle.

The tool box is located in engine compartment on pulley guard.

To remove the tool box from the pulley guard, unlock the tab from underneath the pulley guard and pull the tool box towards front to release it.




TYPICAL  
1. Tool kit

### 14) Grab Handle/Bumper

To be used whenever snowmobile requires manual lifting.


**⚠ WARNING**

Do not attempt to lift the vehicle by hand alone. Use appropriate lifting device or have assistance to share lifting stress in order to avoid risk of strain injuries.



**FRONT**

1. Grab handle/bumper



**REAR**

1. Grab handle/bumper


**NOTICE** Do not use skis to pull or lift snowmobile.

**15) Gauge**


**⚠ WARNING**

Never adjust or set functions on the multifunction gauge while riding the vehicle.

*Analog/Digital Gauge*



*Multifunction Analog/Digital Gauge*




1. Speedometer
2. Tachometer
3. Digital display
4. Multifunction Digital Display
5. Pilot lamps
6. Mode button
7. Set button

**NOTE:** The gauge is factory preset in Imperial units but it is possible to change it to metric units, contact an authorized SKI-DOO dealer for unit settings.

**Speedometer**

Measures vehicle speed (in miles or kilometers depending on the setting).



LH PORTION OF GAUGE

### Tachometer (RPM)

Measures engine revolution per minute (RPM). Multiply by 1000 to obtain the actual revolutions.







RH PORTION OF GAUGE

### Pilot Lamps



TYPICAL — PILOT LAMPS

See table below for usual pilot lamps information.

PILOT LAMP(S) ON	BEEPER	MESSAGE DISPLAY (X AND LIMITED PACKAGE ONLY)	DESCRIPTION
	4 short beeps every 2 minutes	LOW OIL	Injection oil level is low. Stop vehicle in a safe place then, replenish injection oil reservoir.
	—	—	Low fuel level. One (1) bar left in fuel level display. Replenish fuel tank as soon as possible.
	Long beeps repeating slowly	REVERSE	Electronic reverse is selected.
	3 short beeps	REV. FAIL	Engine rotation did not change after reverse try, try again.
	—	—	High beam headlights are selected.
—	—	WARM UP	Engine and/or injection oil need to warm-up before normal operation. The engine's RPM is limited until desired temperature is reached (up to 10 minutes when driving).

Refer to *MONITORING SYSTEM* for details on malfunction pilot lamps.

### MODE (M) Button

#### *Multifunction Analog/Digital Gauge Only*

Button use to navigate in gauge multi-function display.

**NOTE:** MODE (M) button on the multi-switch housing has the same functions and can also be used.

### SET (S) Button

Button use to navigate, adjust or reset gauge multifunction display.

**NOTE:** SET (S) button on the multi-function switch has the same functions and can also be used.

### Digital Display


#### *Analog/Digital Gauge Only*

Digital display that supplies several real time useful information to the driver.


#### **⚠ WARNING**

Reading the gauge digital display can distract from the operation of the vehicle, particularly from constantly scanning the environment. This could lead to a collision resulting in severe injuries or death. Before reading the gauge digital display, ensure your environment is clear and free from obstacle, and bring the vehicle to a low speed. Before proceeding with any adjustments, park vehicle in a safe place and away from the trail.

The digital display is factory preset in Imperial units but it is possible to change it to metric units, contact an authorized SKI-DOO dealer for unit settings.



ANALOG/DIGITAL GAUGE  
1. Digital display




1. Odometer mode

### B) Trip Meter "A" or "B"

Trip meters records distance travelled since it has been reset.

Press the SET (S) button to select trip meter (TRIP A/TRIP B) mode.



1. Trip meter (TRIP A/TRIP B) mode

Press and hold the SET (S) button to reset.

DISPLAY FEATURES	
FUNCTIONS	REFER TO TOPICS
Odometer	A)
Trip meter "A" or "B"	B)
Trip hour meter	C)
Fuel level	D)
Engine coolant temperature (not factory installed)	E)

**NOTE:** The display is factory preset in Imperial units but it is possible to change it to Metric units, contact an authorized SKI-DOO dealer for unit settings.

### A) Odometer

Records the total distance travelled.


Press the SET (S) button to select odometer mode.



### C) Trip Hour Meter


Records vehicle running time when the electrical system is activated since it has been reset.

Press the SET (S) button to select trip hour meter (HrTRIP) mode.




1. Trip hour meter (HrTRIP) mode

Press and hold the SET (S) button to reset.



## D) Fuel Level

Bar gauge that continuously indicates the amount of fuel left in the fuel tank.



### FUEL LEVEL

1. Operating range

## E) Engine Coolant Temperature

A BRP accessory allowing the engine coolant temperature to be displayed can be added to the digital display. Contact an authorized SKI-DOO dealer for more information.

## Multifunction Digital Display


### Multifunction Analog/Digital Gauge Only

Multifunction digital display that supplies several real time useful information to the driver either in English or French, contact an authorized SKI-DOO dealer for language settings.

## ! WARNING

Reading the gauge digital display can distract from the operation of the vehicle, particularly from constantly scanning the environment. This could lead to a collision resulting in severe injuries or death. Before reading the gauge digital display, ensure your environment is clear and free from obstacle, and bring the vehicle to a low speed. Before proceeding with any adjustments, park vehicle in a safe place and away from the trail.

Also, the multifunction digital display is factory preset in Imperial units but it is possible to change it to Metric units, contact an authorized SKI-DOO dealer for unit settings.



### MULTIFUNCTION ANALOG/DIGITAL GAUGE


1. Multifunction display

DISPLAY FEATURES	
FUNCTIONS	REFER TO TOPICS
Speedometer	A)
Tachometer (RPM)	B)
Odometer	C)
Trip meter "A" or "B"	D)
Trip hour meter	E)
Clock	F)
Fuel level	G)
Altitude	H)
Top speed	I)
Average speed	J)
Heated grips heating intensity	K)
Heated throttle lever heating intensity	L)
Instant fuel consumption	M)
Total fuel consumption	N)
Message Display	O)

**A) Speedometer**

In addition of the analog type speedometer, vehicle speed can also be displayed via the multifunction display.

Vehicle speed can be displayed on display 1 or display 2.




**MULTIFUNCTION DISPLAY**

1. Display 1
2. Display 2

Use MODE (M) button to select the desired display, then proceed as follows:




While display is flashing, press the SET (S) button to select speedometer mode.



1. Speedometer mode

Press the MODE (M) button to confirm selection or wait 5 seconds.







**B) Tachometer (RPM)**

In addition of the analog type tachometer, RPM can also be displayed via the multifunction display.

Engine RPM can be displayed on display 1 or display 2.

1. RPM mode

Press the MODE (M) button to confirm selection or wait 5 seconds.



**MULTIFUNCTION DISPLAY**


1. Display 1
2. Display 2

Use MODE (M) button to select the desired display, then proceed as follows:

**C) Odometer**

Records the total distance travelled.

Press the SET (S) button to select odometer mode.




1. Odometer (km/mi) mode

**D) Trip Meter "A" or "B"**

Trip meters records distance travelled since it has been reset.

Press the SET (S) button to select trip meter (TRIP A/TRIP B) mode.


While display is flashing, press SET (S) button to select RPM mode.



1. Trip meter (TRIP A/TRIP B) mode

Press and hold the SET (S) button to re-set.


**NOTE:** On E-TEC models, resetting TRIP B mode will also reset TOTAL FUEL CONSUMPTION.



F) Clock

**Electric Start Models**


Press the SET (S) button to select clock mode.



E) Trip Hour Meter


Records vehicle running time when the electrical system is activated since it has been reset.

Press the SET (S) button to select trip hour meter (HrTRIP) mode.




1. Clock mode

Press and hold the SET (S) button to activate clock set-up.



1. Trip hour meter (HrTRIP) mode

Press and hold the SET (S) button to re-set.




To change HOURS, while the value of HOURS is blinking, use the SET (S) button to change hours.

To change MINUTES, while the value of HOURS is blinking, press the MODE (M) button to switch to minutes. Use the SET (S) button to change minutes.

Press the MODE (M) button to save clock set-up and exit mode.

### G) Fuel Level

Bar gauge that continuously indicates the amount of fuel left in the fuel tank.



#### FUEL LEVEL

1. Operating range


### H) Altitude

Displays vehicle **approximate** altitude above sea level calculated from the barometric pressure.


**NOTE:** Altitude displayed is rounded off every 100 meters or 200 feet.

To display vehicle altitude, proceed as follows.

Press the MODE (M) button to select display 1.



While display is flashing, press the SET (S) button to select altitude mode.




1. Altitude mode

The following symbol appears when altitude mode is selected.



#### ALTITUDE MODE

Press the MODE (M) button to confirm selection or wait 5 seconds.



### I) Top Speed

Records vehicle top speed since it has been reset.

To display vehicle top speed, proceed as follows.


Press the MODE (M) button to select display 1.



While display flashes, press the SET (S) button to select top speed (TOP\_SPD) mode.




Press and hold the SET (S) button within 5 seconds to reset.



1. Top speed (TOP\_SPD) mode

Press the MODE (M) button to confirm selection or wait 5 seconds.




## J) Average Speed


Records vehicle average speed since it has been reset.

To display vehicle average speed, proceed as follows.


Press the MODE (M) button to select display 1.



To reset, press the MODE (M) to select mode.



While display flashes, press SET (S) button to select vehicle average speed (AVR\_SPD) mode.




1. Vehicle average speed (AVR\_SPD) mode

Press the MODE (M) button to confirm selection or wait 5 seconds.



To reset, press the MODE (M) to select mode.




Press and hold the SET (S) button within 5 seconds to reset.



K) Heated Grips Heating Intensity

Bar gauge that indicates heating intensity.

Refer to *HEATING GRIPS SWITCH* for more details.



*HEATING GRIPS*


1. Operating range

L) Heated Throttle Lever Heating Intensity

Bar gauge that indicates heating intensity.

Bar gauge will be displayed instead of the fuel level with the activation of the heating throttle lever switch. When released, display will return to fuel level.

Refer to *HEATING THROTTLE LEVER SWITCH* for more details.



**HEATING THROTTLE LEVEL**  
1. Operating range

**M) Instant Fuel Consumption**

**600 HO E-TEC Models Only**


Calculates vehicle average fuel consumption while riding.

To display vehicle average fuel consumption, proceed as follows.

Press the MODE (M) button to select display 1.




While display flashes, press SET (S) button to select instant fuel consumption mode.



1. Instant fuel consumption mode

Press the MODE (M) button to confirm selection or wait 5 seconds.



**N) Total Fuel Consumption**


**600 HO E-TEC Models Only**

Records vehicle average fuel consumption since it has been reset.


**NOTE:** The TRIP B odometer has to be selected to allow this function, refer to *TRIP METER "A" OR "B"* for more details.

To display vehicle total fuel consumption, proceed as follows.

Press the MODE (M) button to select display.




While display flashes, press the SET (S) button to select total fuel consumption (TC) mode.




1. Total fuel consumption (TC) mode

TC appears when the mode is selected.




1. Trip meter (TRIP B) mode

Press and hold the SET (S) button to re-set.




TYPICAL


Press the MODE (M) button to confirm selection or wait 5 seconds.



## O) Message Display



To reset, set the trip meter to TRIP B. Refer to *TRIP METER "A" OR "B"* for more details.



1. Message display

Refer to *PILOT LAMPS* in this section for details on usual messages.

Refer to *MONITORING SYSTEM* for details on malfunction and DESS related messages.

## 16) Holding Strap

### *Summit and Renegade X Models*

Holding strap provides a grip for driver when side-hilling.

**⚠ WARNING**

This strap is not for towing, lifting or other purpose than temporary use as a grab handle during side-hilling. Always keep at least one hand on handlebar.


**17) Storage Compartment**

**⚠ WARNING**

All storage compartments must be properly latched and they must not contain any sharp, heavy or breakable objects.

**NOTICE** MAXIMUM load is 1.8 kg (4 lb) evenly distributed.

Pull latch slightly upward then, backward to unlock cover.



1. Storage compartment  
2. Latch

**18) Rear Rack**

**⚠ WARNING**

All objects in rear rack must be properly latched. Do not carry any breakable objects. Excessive weight in rack may reduce steering ability.

**NOTICE** Always readjust suspension according to the load. The capacity of this rack is limited, the MAXIMUM cargo load is 15.8 Kg (35 lb). Ride at very low speed when loaded. Avoid speed over bumps.

**19) Integrated Bag**

*GSX Only*

On the above mentioned model, a sport tunnel bag is provided as standard equipment.

**⚠ WARNING**

Integrated bag must be properly latched and must not contain any sharp, heavy or breakable objects.

**NOTICE** MAXIMUM load for this bag is 1.4 kg (3 lb) evenly distributed.



**20) 1+1 Seat**

*GTX Only*

On the above mentioned models, a 1+1 passenger seat is provided as standard equipment.




## **⚠ WARNING**


Any passenger must be able to firmly lay his feet on the footrests and keep his hands on the grab handles at all times when seated. Respecting those physical criteria is important to ensure that the passenger is stable and to reduce the risks of ejection.

### **1+1 Seat Removal**

Unplug 1+1 seat connector.




1. Connector location




1. Connector

Push and hold seat latch while gently lifting rear of seat.



1. Seat latch location



1. Seat latch

Continue lifting movement until you can release the front retaining device then completely remove seat.




1. Retaining device

**NOTICE** Make sure to unplug seat harness before removing seat.

### **1+1 Seat Installation**

Insert seat retaining device into set base.




1. Retaining device

When seat rests in its position, firmly push seat down to latch.

**NOTE:** A distinctive snap will be felt. Double check that the seat is secure by giving it a tug to confirm proper latching.



Connect 1+1 seat connector.



1. Connector

## 21) Rear Grab Handles


*GTX Only*

Rear grab handles provides a grip for the passenger.

## 22) Rear Passenger Heating Grip Switch

*GTX Only*

Three-position switch. Select the desired position to keep rear passenger's hands at a comfortable temperature.



**PASSENGER LH GRAB HANDLE**

1. Switch
2. LH grab handle

## 23) Electric Visor Jack Connector

An electric visor can be connected to the jack connector. Electric current is supplied whenever engine is running. A stress relief extension is supplied with the vehicle.

## 24) 12-Volt Power Outlet

*GTX and GSX Limited Only*


A 12-volt electric appliance may be connected to that jack connector. Electric current is supplied whenever engine is running.

## 25) C-Type Hitch

*Renegade and Summit Everest (European Models Only)*


Use this hitch in conjunction with a tow bar to tow an accessory.

**NOTE:** Refer to decal on vehicle for towing weight capacities.




## How to Use the C-Type Hitch

Detach hitch from its support by removing the hairpin.




1. Hitch
2. Hairpin

Remove rod from hitch then attach rigid tow bar to hitch using the same rod.




- TYPICAL**
1. Rod

Secure rod to hitch using hairpin previously removed.




- TYPICAL**
1. Hairpin
  2. Rod

**NOTICE** To avoid damages to the vehicle, always release hitch from its support. Ensure hitch moves freely when towing accessories.



**HITCH MOVES FREELY WHEN TOWING**

To avoid noise from hitch when not in use, secure hitch to its support by using the hairpin.



- HITCH NOT IN USE**
1. Hitch
  2. Support
  3. Hairpin

# FUEL AND OIL

## Recommended Fuel

Use unleaded gasoline available from most service stations or oxygenated fuel containing a maximum total of 10% of ethanol or methanol or both. The gasoline used must have the following recommended minimum octane number.

OCTANE NUMBER				
Inside North America				
(87 (RON + MON)/2)				
(91 (RON + MON)/2)				
Outside North America				
92 RON				
95 RON ▼ ▼ ▼ ▼				
ENGINES	95	92	91	87
500SS	X	X	X	X
600 HO E-TEC	X	—	X	—
800R Power TEK	X	—	X	—

**NOTICE** Never experiment with other fuels. The use of not recommended fuel can result in snowmobile performance deterioration and damage to critical parts in the fuel system and engine components. Do not mistake oil reservoir cap for fuel tank cap. Oil reservoir cap is identified OIL.

## Fuel Antifreeze Additives

When using oxygenated fuel, additional gas line antifreeze or water absorbing additives are not required and should be not used.


When using non-oxygenated fuel, we highly recommend the use of isopropyl base gas line antifreeze in a proportion of 150 ml (5 U.S. oz) of gas line antifreeze added to 40 liters (10-1/2 U.S. gal) of gas.

This precaution is in order to reduce the risk of frost buildup in carburetors or other fuel system components which may lead, in certain cases, to severe damage to engine.

**NOTE:** Use only methyl hydrate free gas line antifreeze.

## Fueling Procedure

Unscrew to fill up tank then fully tighten.



**TYPICAL**

1. Fuel tank cap

## ⚠ WARNING

Always stop the engine before refueling. Fuel is flammable and explosive under certain conditions. Always work in a well ventilated area. Do not smoke or allow open flames or sparks in the vicinity. Open cap slowly. If a differential pressure condition is noticed (whistling sound heard when loosening fuel tank cap) have vehicle inspected and/or repaired before further operation. Do not overfill or top off the fuel tank before placing the vehicle in a warm area. As temperature increases, fuel expands and might overflow. Always wipe off any fuel spillage from the vehicle. Periodically verify fuel system.

**NOTE:** Do not sit or lean on seat when fuel tank cap is not properly installed.

## Recommended Oil

**NOTICE** Do not mismatch oil reservoir cap with fuel tank cap. Oil reservoir cap is identified OIL.

ENGINES	RECOMMENDED INJECTION OIL
500SS	XP-S synthetic blend <sup>(1)</sup>
600 HO E-TEC	
800R Power TEK	

**NOTICE** <sup>(1)</sup> These engines were specifically developed and tested with XP-S Synthetic Blend 2-stroke oil (P/N 293 600 101). The use of any other 2-stroke engine oils may cause severe engine damage and may void the limited warranty. Use only XP-S synthetic blend 2-stroke oil.


The XP-S synthetic blend provides superior lubrication, reduced engine component wear and oil deposit, thus maintaining maximum-level performance and antifriction properties. The synthetic blend injection oil meets the latest ASTM and JASO standards by ensuring high biodegradability and low exhaust smoke.

## Injection Oil Level

Always maintain a sufficient amount of recommended injection oil in the injection oil reservoir.

Unscrew injection oil reservoir cap to fill up reservoir then fully tighten.

**NOTICE** Check level and refill every time you refuel.



### TYPICAL

1. Injection oil reservoir
2. Level marks (1/4, 1/2, 3/4)

## **⚠** WARNING

Do not overfill. Reinstall cap and fully tighten. Wipe off any oil spills. Oil is highly flammable when heated.

---

# OPERATING INSTRUCTIONS

## Operating During Break-In

### Engine

**NOTICE** A break-in period of 10 operating hours - 500 km (300 miles) - is required before running the snowmobile at full throttle.

During break-in period, maximum throttle should not exceed 3/4 opening. However, brief full acceleration and speed variations contribute to a good break-in.

**NOTICE** Engine overheating, continued wide open throttle runs and prolonged cruising without speed variations should be avoided, this can cause engine damage during the break-in period.

### *500SS and 800R Engines Only*

To assure additional protection during the initial engine break-in, 500 ml (18 imp. oz) of recommended injection oil should be added to fuel for the first full filling of fuel tank. Have spark plugs cleaned after engine break-in.

### Belt

A new drive belt requires a break-in period of 50 km (30 miles). Avoid strong acceleration/deceleration, pulling a load or high speed cruising.

### 10-Hour Inspection

We suggest that after the first 10 hours or 500 km (300 miles), of operation whichever comes first, your snowmobile be checked by an authorized SKI-DOO dealer. Refer to *MAINTENANCE INFORMATION* section.

## Engine Starting Procedure (500SS/800R)

### Procedure

1. Recheck throttle control lever operation.

2. Ensure that the tether cord cap (DESS key) is in position and that the cord attached to your clothing eyelet.
3. Ensure that the engine stop switch is in the ON position.
4. Activate the choke according to the temperature. Refer to *CHOKE APPLICATION* further.
5. Start engine as explained below.

### **WARNING**

Never depress throttle while starting engine.

### Manual Start

Grab rewind starter handle, pull handle slowly until a resistance is felt, then hold handle firmly and pull vigorously to start engine.

### Electric Start Models

Depress the START/RER button to engage the electric starter and start the engine. Release button immediately when engine has started.

**NOTE:** If for any reason, the engine cannot be started electrically, start engine manually using the rewind starter.

**NOTICE** Do not engage electric starter for more than 10 seconds at a time. A rest period should be observed between the cranking cycles to allow electric starter to cool down.


### Choke Application

**Initial Cold Starting When Temperature is Below - 10°C (+ 15°F)**

**NOTE:** Do not operate the throttle lever with the choke lever on.

Set the choke lever to position 3.

**NOTE:** After the engine is started, let engine warm up at fast idle until engine speed drops. Then, close off choke to ensure proper air-fuel mixture.



1. OFF
2. Position 2
3. Position 3

### Initial Cold Starting When Temperature is Above - 10°C (above + 15°F)

Set the choke lever to position 2.

**NOTE:** After the engine is started, close off choke to ensure proper air-fuel mixture.

### Warm Engine Starting

Start the engine without any choke. If the engine will not start after two pulls of the rope or two 5 second attempts with the electric starter move choke lever to position 2. Start the engine without activating the throttle lever. As soon as the engine starts move the choke lever to OFF.

## Engine Starting Procedure (600 HO E-TEC)

### Procedure

1. Recheck throttle control lever operation.
2. Ensure that the tether cord cap (DESS key) is in position and that the cord is attached to your clothing eyelet.
3. Ensure that the engine stop switch is in the ON position.
4. Start engine as explained below.

### **⚠ WARNING**

Never depress throttle while starting engine.

### Manual Start Models

Grab rewind starter handle, pull handle slowly until a resistance is felt, then hold handle firmly and pull vigorously to start engine.

### Electric Start Models

Depress the START/RER button to engage the electric starter and start the engine. Release button immediately when engine has started.

**NOTICE** Do not engage electric starter for more than 10 seconds at a time. A rest period should be observed between the cranking cycles to allow electric starter to cool down.

### Emergency Starting

The engine can be started with the emergency starter rope supplied with the tool kit.

Remove belt guard.


### **⚠ WARNING**

Do not wind starting rope around your hand. Hold rope by the handle only. Do not start the snowmobile by the drive pulley unless it is a true emergency situation. Have the snowmobile repaired as soon as possible.




Attach one end of emergency rope to rewind handle.


**NOTE:** The spark plug socket can be used as an emergency handle.



Attach the other end of emergency rope to the starter clip supplied in the tool kit.




Hook up clip on drive pulley.



1. Clip installation location

Wind the rope tightly around drive pulley. When pulled, pulley must rotate counterclockwise.



Pull the rope using a sharp, crisp pull so the rope comes free of the drive pulley. Start engine as per usual manual starting.

**⚠ WARNING**

When starting the snowmobile in an emergency situation, using drive pulley, do not reinstall the belt guard and return slowly to have snowmobile repaired.

## Riding Conditions and your Snowmobile

### Altitude

Ensure your model is calibrated for the altitude you are riding at.

**NOTICE** Failure to re-calibrate may cause serious engine damage.

MODEL(S)	FACTORY CALIBRATION
GSX, GTX and MX Z	Sea level up to 600 m (2000 ft)
SUMMIT (North America)	Within 600 – 2400 m (2000 – 8000 ft)
SUMMIT (Europe)	Sea level up to 600 m (2000 ft)

Refer to an authorized SKI-DOO dealer for proper calibration modifications if required.



## Temperature

### 500SS

This engine has been calibrated for - 20°C (- 4°F). They can be operated at warmer winter temperatures without risk of problems.

**NOTICE** For colder temperatures than - 20°C (- 4°F), carburetor(s) must be recalibrated to avoid engine damage. Refer to an authorized SKI-DOO dealer.

## Hard Packed Snow

### Summit Series

Generally, snowmobiles adapted for mountain riding comes with tracks equipped with a lug profile of 44.5 mm (1.75 in) or Higher. These tracks are optimized for operation on loose snow.

BRP does **not recommend** to ride a snowmobile equipped with high lug profile track at **high speed** in a trail, on hard packed surfaces or ice for an extended period of time.

In the event that you have to, **reduce your speed**, then minimize the distance you ride on those surfaces.

**NOTICE** Running those tracks at high speed in a trail, on hard packed surfaces or ice put more stress on the lugs, which tend to heat up as a result. To avoid potential degradation or damage to the track, reduce your speed, then minimize the distance you ride on those surfaces.

For general instructions on maintenance of tracks, refer to the *TRACK* in *MAINTENANCE INFORMATION*.

## Vehicle Warm-Up

Before every ride, vehicle has to be warmed up as follows.

Engage parking brake.

Snowmobile must be securely supported by the rear bumper using a wide-base snowmobile mechanical stand. Track must be 100 mm (4 in) off the ground.

Attach tether cord to operator's clothing eyelet.

Start engine and allow it to warm up two or three minutes at idle speed.

**NOTE:** It is not recommended to let engine running at idle speed for more than 10 minutes.

Disengage parking brake.

## WARNING

**Make sure wide-base snowmobile mechanical stand is stable. Never take place in front or behind the snowmobile. Do not use too much throttle during warm-up or when track is free-hanging.**

Apply throttle until drive pulley engages. Let track rotate at low speed for several turns. The lower the vehicle temperature, the longer vehicle warm-up should be.

Shut-off the engine and remove the wide-base snowmobile mechanical stand.

Skis may be frozen on the ground. Grab both skis one at a time by their loops and lift their front end slightly off the ground.

After restarting engine, the vehicle can be driven at low speed for the first 2 or 3 minutes of riding. After that, it may be driven up to the legal speed limit as per normal safety practices.

## Reverse (RER)

When the engine is running, depressing the RER button will slow down engine RPM to almost a stop and advance the ignition timing to invert crankshaft rotation.

- Engine will automatically shift into forward when restarting after stopping or stalling.
- Shifting procedure will take place only when the engine is running.
- If engine is running at a speed above 4300 RPM, the function of the RER button is disabled.
- It is recommended to warm up the engine to its normal operating temperature before shifting.

## Shifting in Reverse

### WARNING

Engaging the reverse mode is done by depressing the RER button when the engine is running. Wait until the reverse alarm sounds and the RER pilot lamp comes on in the analog/digital gauge before operating throttle to proceed in reverse. The reverse speed is not limited. Always proceed with caution as fast reverse could result in loss of vehicle stability. Come to complete stop before depressing RER button. Always remain seated and apply the brake before shifting. Ensure the path behind is clear of obstacles or bystanders before proceeding.

With the snowmobile completely stopped and engine running at idle, press and release the RER button.

The RER pilot lamp will blink when the snowmobile is engaged in reverse.

Apply throttle slowly and evenly. Allow drive pulley to engage then accelerate carefully.

## Shifting in Forward

With the snowmobile completely stopped and engine running at idle, press and release the RER button.

RER pilot lamp will stop.

Apply throttle slowly and evenly. Allow drive pulley to engage then accelerate carefully.

## Shutting Off the Engine

Release throttle lever and wait until engine has returned to idle speed.

Shut off the engine using either engine stop switch or pulling off the tether cord cap (DESS key).

### WARNING

Always remove the tether cord cap (DESS key) from post when vehicle is not in operation in order to prevent accidental engine starting or to avoid unauthorized use by children or others or theft.

## Towing an Accessory

Always use a rigid tow bar to tow an accessory. Any towed accessory should have reflectors on both sides and at the rear. Check local laws for brake light(s) requirements.

### WARNING

Never tow an accessory with a rope. Always use a rigid tow bar. Using a rope would result in a collision between the object and the snowmobile and possibly in a tip over in case of a rapid deceleration or on a downward slope.

## Towing Another Snowmobile

If a snowmobile is disabled and must be towed use a rigid tow bar. Remove the drive belt from disabled snowmo-

bile, refer to *DRIVE BELT* in the *MAINTENANCE PROCEDURE* section and tow at moderate speed.

**NOTICE** Always remove the drive belt of the snowmobile that is to be towed to prevent damage to its belt and drive system.

In an emergency situation only, if a rigid tow bar is not available, a rope can be used provided you proceed with extra caution. In some areas, it may be illegal to do so. Check with state or local authorities.

Remove the drive belt, attach the rope to the ski legs (spindles), have someone sit on the towed snowmobile to activate the brake, and tow at low speed.

**NOTICE** In order to prevent damage to the steering system, never attach the tow rope to the ski loops (handles).

**⚠ WARNING**

Never ride at high speed when towing a disabled snowmobile. Proceed slowly with extra caution.

## Post-Operation Care

Install rear of vehicle on a wide-base snowmobile mechanical stand.

Remove snow and ice from rear suspension, track, front suspension, steering mechanism and skis.

Always cover your snowmobile when leaving it outside overnight or during extended periods of inactivity. This will protect it from frost and snow as well as help retain its appearance.

# TUNE YOUR RIDE

## **⚠ WARNING**

Suspension adjustment could affect vehicle handling. Always take time to familiarize yourself with the vehicle's behavior after any suspension adjustment have been made.

Snowmobile handling and comfort depend upon suspension adjustments.

Choice of suspension adjustments vary with carrying load, driver's weight, personal preference, riding speed and field condition.

**NOTE:** Some adjustments may not apply to your snowmobile. Use special keys in tool kit.

## **⚠ WARNING**

Before proceeding with any suspension adjustment, remember:

- Park in a safe place.
- Remove the tether cord cap (DESS key).
- Lift the front of vehicle off the ground with a suitable lifting device before adjusting suspension.
- Lift rear of vehicle off the ground with a wide-base snowmobile stand with a rear deflector panel.
- Make sure lifting device is stable and secure.


## **⚠ WARNING**

Do not attempt to lift the vehicle by hand alone. Use appropriate lifting device to avoid risk of strain injuries.

**NOTE:** Some models may come from factory equipped with Take/Apart (T/A) shocks. These can be rebuilt or recalibrated. See an authorized SKI-DOO dealer.


## Rear Suspension Adjustment

REAR SUSPENSION TYPE		
MODELS	TYPE	
	SC-5M	SC-5
Summit	X	—
Others	—	X



### SC-5 REAR SUSPENSION

1. Rear springs adjustable cams for comfort and ride height
2. Center spring for steering behavior
3. Stopper strap for snowmobile weight transfer
4. Coupling blocks — handling
5. Rear shock motion ratio — damping strength (not adjustable on all models)



### SC-5M REAR SUSPENSION

1. Rear springs adjustable cams for comfort and ride height
2. Center spring for steering behavior
3. Stopper strap for snowmobile weight transfer
4. Rear shock motion ratio — damping strength (not adjustable)

Following are guidelines to fine-tune suspension.

The best way to set up the suspension, is to start from factory settings, then customize each adjustment one at a time. It may be necessary to readjust center spring after adjusting front springs for instance. Test run the snowmobile under the same conditions; trail, speed, snow, driver riding

position, etc. Change one adjustment and retest. Proceed methodically until you are satisfied.


**NOTICE** Whenever adjusting rear suspension, check track tension and adjust as necessary.

Slight suspension bottoming occurring under the worst riding conditions indicates a good choice of spring preload.

### Rear Springs Preload (Comfort)

**IMPORTANT:** Make sure that all objects to be transported are in place in storage compartment and rear rack.

- Grab rear bumper and lift until suspension is fully extended.
- From this point, rear of snowmobile should collapse by 50 to 75 mm (2 to 3 in) when driver and passenger (if so applicable) take place. Measure at rear bumper as shown in next illustration.



#### TYPICAL — PROPER ADJUSTMENT

- Suspension fully extended
- Suspension has collapse with driver, passenger(s) and load added
- Distance between dimension "A" and "B", must not exceed 50 to 75 mm (2 to 3 in), see table


### Reference Table

"C"	WHAT TO DO
50 to 75 mm (2 to 3 in)	No adjustment required
More than 75 mm (3 in)	Adjusted too soft, Increase preload (see preload adjustment)
Less than 50 mm (2 in)	Adjusted too hard, Decrease preload (see preload adjustment)

### Preload Adjustment


CAM POSITIONS	SPRING PRELOAD
1	Minimum
2	Minimum/intermediate
3	Intermediate
4	Intermediate/maximum
5	Maximum

**NOTICE** To adjust spring preload, always turn the left side adjustment cam in a clockwise direction, and the right side cam in a counterclockwise direction.




#### TYPICAL — SC-5 — LH SIDE


- Adjust spring preload



TYPICAL — SC-5M — LH SIDE  
1. Adjust spring preload



TYPICAL — SC-5 — RH SIDE  
1. Adjust spring preload



TYPICAL — SC-5M — RH SIDE  
1. Adjust spring preload

### Center Spring Preload (Steering Behavior)


Ride at moderate speed on a trail.

If handlebar seems too easy or too hard to turn, adjust center spring accordingly.

### Reference Table

STEERING BEHAVIOR	WHAT TO DO
Easy to turn (neutral)	No adjustment required
Harder to turn (oversteering)	Adjusted too soft, increase preload
Very easy to turn (understeering)	Adjusted too hard, decrease preload

### Preload Adjustment



#### TYPICAL

1. Turn spring preload adjuster to increase or decrease preload
2. Turn clockwise to increase spring preload
3. Turn counterclockwise to decrease spring preload

### Stopper Strap length (Weight Transfer)

Ride at low speed then fully accelerate. Note steering behavior.


Adjust stopper strap length accordingly.

**NOTICE** Whenever stopper strap length is changed, track tension must be readjusted.

## Reference Table


WEIGHT TRANSFER (SKI PRESSURE)	WHAT TO DO
Comfortable: good weight transfer (light pressure)	No adjustment required
Light: too much weight transfer (lift off the ground)	Strap too long, reduce strap length
Heavy: not enough weight transfer (heavy pressure)	Strap too short, increase strap length

## Stopper Strap Adjustment



TYPICAL — SC-5

1. Increase or decrease strap length by bolting to a different hole



TYPICAL — SC-5M

1. Increase or decrease strap length by bolting to a different hole

**NOTE:** Decreasing the stopper strap length may reduce comfort. If too much weight transfer is felt, try to correct it by adjusting the coupling blocks first.

## Deep Snow Riding

When operating the snowmobile in deep snow, it may be necessary to vary stopper strap length and/or riding position, to change the angle at which the track rides on the snow. Operator's familiarity with the various adjustments as well as snow conditions will dictate the most efficient combination.

## Coupling Blocks (Handling)

### SC-5 Suspension Only

Coupling blocks will have an effect on vehicle handling while accelerating.

A minimum coupling adjustment while accelerating will generate **less** pressure on the skis.

At the opposite, a maximum coupling adjustment will generate **more** pressure on the skis.

Perform moderate acceleration from a stand point or while riding and check for desired handling.

If handling requires adjustment, turn both left and right blocks by 90° to the desired position.


**NOTE:** There are four possible adjustment positions. Side of block with the desired adjustment number must be facing the rubber stopper.

## **⚠ WARNING**

Both blocks must be set at the same position. Otherwise vehicle behavior may be unpredictable and suspension may become warped.

Use tool provided in tool bag to adjust coupling blocks.

**NOTE:** When in driving position, the coupling blocks should not touch the rubber stoppers.



**COUPLING BLOCK — LEFT SIDE VIEW**  
 ("L" — LEFT EMBOSSED ON BLOCK)

1. Position 1 (minimum)
2. Position 2 (minimum/intermediate)
3. Position 3 (intermediate/maximum)
4. Position 4 (maximum)

## Rear Shock Compression Damping

### *HPG Clicker and Racing Clicker Only*


Rear shock on the above mentioned models feature 2 adjustments.

### Low Speed Compression Damping

The low speed adjuster modifies the compression damping force for small suspension velocities. This adjuster has 5 turns of adjustment. Use a flat screwdriver to adjust it. Turning it clockwise increases shock damping action (stiffer) for these low compression speeds.

### High Speed Compression Damping

The high speed adjuster modifies the compression damping force for high suspension velocities. Use a 17 mm wrench to adjust it. Turning it clockwise increases shock damping action (stiffer) for these high compression speeds.



### TYPICAL


1. Low speed compression adjuster (flat screwdriver)
2. High speed compression adjuster (17 mm wrench)

## Front Suspension Adjustments

### Front Springs Preload (Handling)

Ride at moderate speed and check for proper handling.

Adjust front springs accordingly.



### FRONT SUSPENSION

1. Front springs for handling

**⚠ WARNING**


Always adjust both front springs to same position.




## Reference Table

HANDLING	WHAT TO DO
Good: steering comfortable to turn	No adjustment required
Bad: steering too easy to turn	Adjusted too soft, increase spring preload
Bad: steering too hard to turn	Adjusted too hard, decrease spring preload


## Preload Adjustment

**CAM TYPE PRELOAD WITH DAMPING ACTION ADJUSTMENT**

1. Adjustment cam
2. Cam positions
3. Compression/rebound adjustment

**RING TYPE PRELOAD**

1. Adjustment ring
2. Ring positions

**CAM TYPE PRELOAD**

1. Adjustment cam
2. Cam positions

**NOTICE** Make sure that both front springs are still pre loaded when front of vehicle is off the ground.


## Front Shock Damping

*HPG Clicker and Racing Clicker Only*

## Compression/Rebound Damping

Front shock on the above mentioned models feature a compression/rebound adjustment.

Turn the damping adjuster accordingly. Turning it clockwise increases shock damping action (stiffer).

**TYPICAL**

1. Damping adjuster

## Vehicle Behavior Related to Suspension Adjustment

PROBLEM	CORRECTIVE MEASURES
Front suspension wandering	Check ski alignment and camber angle adjustment. See an authorized SKI-DOO dealer. Reduce ski ground pressure. <ul style="list-style-type: none"> <li>– Reduce front suspension spring preload.</li> <li>– Increase center spring preload.</li> <li>– Reduce rear spring preload.</li> </ul>
Snowmobile seems unstable and seems to pivot around its center	Reduce rear suspension front arm pressure. <ul style="list-style-type: none"> <li>– Reduce center spring preload.</li> <li>– Increase rear spring preload.</li> <li>– Increase front suspension spring preload.</li> </ul>
Steering feels too heavy	Reduce ski ground pressure. <ul style="list-style-type: none"> <li>– Reduce front suspension spring preload.</li> <li>– Increase center spring preload.</li> </ul>
Rear of snowmobile seems too stiff	Reduce rear spring preload.
Rear of snowmobile seems too soft	Increase rear spring preload.
Rear suspension front shock absorber is frequently bottoming	Lengthen stopper strap. Increase center spring preload.
Track spins too much at start	Lengthen stopper strap. Adjust coupling blocks towards "position 1".

---

## VEHICLE TRANSPORTATION

Make sure that oil reservoir and fuel tank caps are properly installed.

Tilt bed trailers can easily be equipped with a winch mechanism to afford maximum safety in loading. Simple as it may seem, never drive your snowmobile onto a tilt bed trailer or any other kind of trailer or vehicle. Many serious accidents have resulted from driving up and over a trailer. Anchor your vehicle securely, front and rear, even on short hauls. Be certain all equipment is securely fastened. Cover your snowmobile when trailering to prevent road grime from causing damage.

Be certain your trailer meets state or provincial requirements. Ensure the hitch and safety chains are secure and the brake, turn indicators and clearance lights all function.



# ***MAINTENANCE INFORMATION***

---

## MAINTENANCE SCHEDULE

Maintenance is very important for keeping your vehicle in safe operating condition. Proper maintenance is the owner's responsibility. Perform periodic checks and follow the maintenance schedule.

### **WARNING**

Failure to properly maintain the vehicle according to the maintenance schedule and procedures can make it unsafe to operate.

This section includes instructions for basic maintenance procedures. If you have the necessary mechanical skills and the required tools, you can perform these procedures. If not, see your authorized SKI-DOO dealer.

Other important items in the maintenance schedule that are more difficult and require special tools are best performed by your authorized SKI-DOO dealer.

### **WARNING**

Turn off the engine, remove tether cord cap and follow these maintenance procedures when performing maintenance. If you do not follow proper maintenance procedures you can be injured by hot parts, moving parts, electricity, chemicals or other hazards.

### **WARNING**

Should removal of a locking device (e.g. lock tabs, self-locking fasteners, etc.) be required when undergoing disassembly/assembly, always replace with a new one.

A: ADJUST C: CLEAN I: INSPECT L: LUBRICATE R: REPLACE  *: TO BE PERFORMED BY AN AUTHORIZED SKI-DOO DEALER	<b>*10-HOUR OR 500 KM (300 mi)</b>						
	<b>WEEKLY OR EVERY 240 KM (150 mi)</b>						
	<b>MONTHLY OR EVERY 800 KM (500 mi)</b>						
	<b>EVERY YEAR OR 3200 KM (2000 mi)</b>						
	<b>EVERY 2 YEARS OR 6000 KM (3700 mi)</b>						
	<b>*STORAGE</b>						
<b>*PRESEASON</b>							
<b>PART/TASK</b>							
<b>LEGEND</b>							
<b>ENGINE</b>							
Rewind starter					L,C	I	
Engine motor mounts	I			I		I	
Exhaust system	I			I		I	
Exhaust manifold screws <sup>(1)</sup>	I					I	
Engine lubrication					L		
Cooling system	I			I		I	
Coolant	I				R		
Crankshaft PTO seal						I	
RAVE valves <sup>(2)</sup>				C			
RAVE valves solenoid (E-TEC and Power TEK)				I			
Injection oil filter					R		
Oil injection pump (500SS and 800R)	A			A		A	
Engine stopper				A			
<b>ENGINE MANAGEMENT SYSTEM</b>							
EMS fault codes	I				I		
<b>FUEL SYSTEM</b>							
Fuel stabilizer					(3)		
Fuel filter <sup>(4)</sup>					R		
Fuel lines, fuel rail and connections	I					I	
Carburetor venturi						C	
Throttle body (E-TEC)						C	
Throttle cable	I			I		I	
Air silencer prefilter			I			I	
Fuel injection system (visual inspection)				I		I	

(1) Retighten to specified torque.  
 (2) RAVE valves must be cleaned by an authorized SKI-DOO dealer.

(3) Add to fuel prior to engine lubrication.  
 (4) Fuel filter must be replaced by an authorized SKI-DOO dealer.

PART/TASK	*10-HOUR OR 500 KM (300 mi)										LEGEND
	WEEKLY OR EVERY 240 KM (150 mi)										
											LEGEND
MONTHLY OR EVERY 800 KM (500 mi)											
											LEGEND
EVERY YEAR OR 3200 KM (2000 mi)											
											LEGEND
EVERY 2 YEARS OR 6000 KM (3700 mi)											
											LEGEND
*STORAGE											
											LEGEND
*PRESEASON											
DRIVE SYSTEM											
Drive belt <sup>(5)</sup>	I	I								I	(5) Adjust drive belt height and have the tension checked by an authorized SKI-DOO dealer at every belt replacement.  (6) Tightening torque of drive pulley must be checked at the 10-hour inspection and every year or 3200 km (2000 mi) thereafter.  (7) Driven pulley preload should be checked at the 10-hour inspection and every year or 3200 km (2000 mi) thereafter.  (8) Check track condition before each ride.  (9) Adjust track tension and alignment as required.
Drive pulley <sup>(6)</sup>	I		I	C				I	C		
Driven pulley <sup>(7)</sup>	I		I	C				I	C		
Brake fluid	I	I					R			I	
Brake hose, pads and disk	I	I								I	
Drive chain	A		A					A			
Chaincase oil									R		
Track <sup>(8)</sup>		A									
STEERING											
Steering mechanism <sup>(10)</sup>	I,L		I	L				I,L			(10) Lubricate whenever the vehicle is used in wet conditions (wet snow, rain, puddles).
FRONT SUSPENSION											
Front suspension mechanism <sup>(10)</sup>	I,L		I	L				I,L			(10) Lubricate whenever the vehicle is used in wet conditions (wet snow, rain, puddles).
Skis and runners	I	I						I			
REAR SUSPENSION											
Rear suspension <sup>(10)</sup>	I		I,L					I,L			(10) Lubricate whenever the vehicle is used in wet conditions (wet snow, rain, puddles).
Suspension stopper strap				I				I			



A: ADJUST C: CLEAN I: INSPECT L: LUBRICATE R: REPLACE  *: TO BE PERFORMED BY AN AUTHORIZED SKI-DOO DEALER	<b>*10-HOUR OR 500 KM (300 mi)</b>							<b>LEGEND</b>
	<b>WEEKLY OR EVERY 240 KM (150 mi)</b>							
	<b>MONTHLY OR EVERY 800 KM (500 mi)</b>							
	<b>EVERY YEAR OR 3200 KM (2000 mi)</b>							
	<b>EVERY 2 YEARS OR 6000 KM (3700 mi)</b>							
	<b>*STORAGE</b>							
<b>*PRESEASON</b>								
<b>PART/TASK</b>								
<b>ELECTRICAL SYSTEM</b>								
Spark plugs (500SS and 800R) <sup>(11)</sup>	I		I				R	(11) Before installing new spark plugs at preseason preparation, it is suggested to burn excess storage oil by starting the engine with the old spark plugs. Only perform this operation in a well ventilated area.
Spark plugs (E-TEC)	(12)							
Battery (if so equipped)	I		I			I	I	
Wiring harnesses, cables and lines	I		I			I		
Lighting system (HI/LO beam, brake light, etc.). Engine stop switch and tether cord cap (DESS)	I	I				I		(12) Spark plugs must be inspected or replaced every 3 years or 10 000 km (6200 mi) by an authorized SKI-DOO dealer.
<b>CHASSIS/BODY</b>								
Headlights beam aiming				A			A	—
Engine compartment	C		C			C		
Vehicle cleaning and protection	C		C			C		

---

## 10-HOUR INSPECTION

We suggest that after the first 10 hours or 500 km (300 mi) of operation, whichever comes first, your vehicle be inspected by an authorized SKI-DOO dealer. The initial maintenance is very important and must not be neglected.

**NOTE:** The 10-hour inspection is at the expense of the vehicle owner.

We recommend that this inspection be signed by an authorized SKI-DOO dealer.

---

Date of 10-hour inspection

---

Authorized dealer signature

---


Dealer name

# MAINTENANCE PROCEDURES

## Air Intake Silencer Prefilter

### Air Intake Silencer Prefilter Verification

Ensure that air intake silencer prefilter is properly installed, clean and in good condition.



1. Intake silencer prefilter

If the prefilter is to be cleaned or replaced, see an authorized SKI-DOO dealer.

## Engine Coolant


**⚠ CAUTION** Never open radiator cap when engine is hot.

### Engine Coolant level

Check coolant level at room temperature. Liquid should be at cold level line (engine cold) of coolant tank.

**NOTE:** When checking level at low temperature it may be slightly lower than the mark.

If additional coolant is necessary or if entire system has to be refilled, refer to an authorized SKI-DOO dealer.



### TYPICAL

1. Coolant tank
2. COLD LEVEL line

## Recommended Engine Coolant

Always use ethylene-glycol antifreeze containing corrosion inhibitors specifically for internal combustion aluminum engines.

Cooling system must be filled with BRP premixed coolant (P/N 219 700 362) or with distilled water and antifreeze solution (50% distilled water, 50% antifreeze).

## Exhaust System

### Exhaust System Verification

The tail pipe of the muffler should be centered with the exit hole in the bottom pan. Exhaust system must be free of rust or leaks. Make sure that all parts are securely in place.

Check retaining springs condition and replace if necessary.

The exhaust system is designed to reduce noise and to improve the total performance of the engine. Modification may be in violation of local laws.

**NOTICE** If any exhaust system component is removed, modified or damaged, severe engine damage may result.

## Spark Plugs (500SS/800R)


### Spare Spark Plug Storage

A space is provided in the tool kit to keep spare spark plugs dry and prevent shocks that might affect the adjustment or break them.

**NOTE:** Spare spark plugs are not supplied with snowmobile.

### Spark Plug Removal

1. Open LH side panel, refer to *BODY*.
2. Remove belt guard, refer to *DRIVE BELT GUARD REMOVAL*.
3. Carefully unplug spark plug cables twisting and pulling the cable boots.
4. Using tools from tool kit, unscrew spark plugs one turn.



1. 19 mm socket
2. Screwdriver rod

5. Clean spark plugs and cylinder heads with pressurized air if possible.

### **⚠ WARNING**

Always wear safety goggles when using pressurized air.

6. Unscrew spark plugs completely then remove them.

### Spark Plug Installation

Prior to installation, make sure that the contact surfaces of cylinder head and spark plugs are free of grime.

1. Using a feeler gauge, verify spark plug gap.
2. Replace spark plug if not within specifications.

**NOTICE** Do not attempt to adjust gap on these spark plugs.

ENGINE TYPE	SPARK PLUG GAP (NOT ADJUSTABLE)
500SS and 800R	0.70 to 0.80 mm (.028 to .032 in)

3. Screw spark plugs into cylinder head by hand until it bottoms.
4. Perform the final tightening using the appropriate tools from the tool kit or with a torque wrench and a proper socket.
  - If a torque wrench is used, torque to 27.5 N•m (20 lbf•ft).
  - If the tools from the tool kit are used, tighten 1/2 turn for a new spark plug and 1/10 turn for a used spark plug.
5. Connect spark plug wires.

## Spark Plugs (600 HO E-TEC)

Spark plugs inspection or replacement must be done by an authorized SKI-DOO dealer.

### **⚠ WARNING**

To avoid serious fire hazard, never attempt to check spark efficiency at spark plugs or spark plug wires and never remove spark plugs.


## Engine Stopper

### Engine Stopper Adjustment

The engine stopper is located on the LH front engine support, in front of the drive pulley.

1. Remove DESS key from post.
2. Remove the LH side panel, refer to *BODY*.
3. Remove drive belt guard, refer to *DRIVE BELT GUARD REMOVAL* in this section.

- Loosen the three bolts retaining the engine stopper to the engine support without removing them.



- Engine stopper
- Engine stopper screws
- Drive pulley

- Apply a downward pressure on the engine stopper with your fingers while tightening the screws just enough to obtain contact between the screw heads and the surface of the stopper.
- Torque screws to 10 N•m (89 lbf•in).

**NOTICE** Serious pulley damage can occur if the engine stopper and its screws are not properly installed.

## Brake Fluid

### Recommended Fluid

Always use brake fluid from a sealed container meeting the specification DOT 4 only.


**CAUTION** To avoid serious damage to the braking system, do not use fluids other than the recommended one, nor mix different fluids for topping up.

## Brake Fluid Level


**NOTICE** Vehicle must be on a level surface before checking any fluid levels.

Check brake fluid (DOT 4) in reservoir for proper level. Add fluid (DOT 4) as required.

**NOTICE** Use only DOT 4 brake fluid from a sealed container. Never use any other types of fluid.



- Brake fluid reservoir



- Minimum
- Maximum
- Operating range

## Chaincase Oil

### Recommended Chaincase Oil


Use XP-S synthetic chaincase oil (P/N 413 803 300).

**NOTICE** Use only the recommended type of oil when servicing. Do not mix synthetic oil with other types of oil.

### Chaincase Oil Level

With the vehicle on a level surface, check the oil level by removing the magnetic check plug on the left side of chaincase.

Oil level must reach the threaded hole's lower edge.




1. Magnetic check plug

**NOTE:** It is normal to find metallic particles stuck to magnetic check plug. If bigger pieces of metal are found, remove the chaincase cover and inspect the chaincase parts.

Remove metal particles from magnetic check plug.

To add oil, remove the filler cap on the chaincase cover.



1. Filler cap

Pour recommended oil in chaincase by the filler hole until oil comes out by the magnetic check plug hole. Reinstall magnetic check plug and torque to 6 N•m (53 lbf•in).

## Drive Belt Guard

### Drive Belt Guard Removal

#### **⚠ WARNING**

**NEVER** operate engine:

- Without shields and belt guard securely installed
- With hood and/or side panels opened or removed.


**NEVER** attempt to make adjustments to moving parts while engine is running.

**NOTE:** Belt guard is purposely made slightly oversize to maintain tension on its pins and retainers preventing undue noise and vibration. It is important that this tension be maintained when re-installing.

Remove the tether cord cap (DESS key).

Open engine compartment LH side panel.

Remove retaining pin.



1. Retaining pin

Lift rear portion of guard then release from front tabs by pivoting the guard outwards.

## Drive Belt Guard Installation

When reinstalling belt guard, position its cutaway toward front of snowmobile.


Place the front LH slot of the guard over the longest tab.

Pivot the guard inward to engage the shortest tab in the RH slot.




1. Tabs

Position the grommet over the retaining rod. It may be necessary to slightly lift the console to make room.



1. Retaining rod

Position rear portion of the belt guard over the retainer and secure it using the retaining pin.



1. Retaining pin

## Drive Belt

### Drive Belt Inspection

Inspect belt for cracks, fraying or abnormal wear (uneven wear, wear on one side, missing cogs, cracked fabric). If abnormal wear is noted, probable cause could be pulley misalignment, excessive RPM with frozen track, fast starts without warm-up period, burred or rusty sheave, oil on belt or distorted spare belt. Contact an authorized SKI-DOO dealer.

### Drive Belt Replacement and Adjustment (Ring Type Adjuster)

#### Drive Belt Removal

Remove DESS key from post.


1. Open LH side panel, refer to *BODY*.
2. Remove belt guard, refer to *DRIVE BELT GUARD REMOVAL*.
3. To open the driven pulley and remove the drive belt, loosen the lock nut (do not remove the lock nut).



**DRIVEN PULLEY - RING TYPE**

1. Lock nut
2. Adjustment ring

To loosen the lock nut, use the following tools from the tool kit.




**SCREWDRIVER PIN**




**WRENCH SOCKET 16/18 MM**

Insert the screwdriver pin into the 16 mm wrench socket.



1. 16 mm end
2. 18 mm end
3. Screwdriver pin

4. Insert and set the 18 mm socket end on the lock nut.




**INSERT TOOL**

5. Loosen lock nut by turning the tool counterclockwise ( $\pm 4$  turns).




**TURN TOOL COUNTERCLOCKWISE**

6. Insert the tool pins in the ring holes and turn clockwise. Completely open the driven pulley by using the suspension adjustment tool.



**SUSPENSION ADJUSTMENT TOOL**






mnr2008-042-001\_a

1. Suspension adjustment tool
2. Adjustment ring

7. Remove the drive belt, by slipping it over the top of the driven pulley.



mno2008-003-045\_a

1. Arrow pointing the front of vehicle

**NOTE:** If your drive belt was broken while riding, you will need to open the driven pulley sheaves first before trying to install a new belt. Refer to *DRIVE BELT REMOVAL* for procedure.

Install drive belt.

1. Set drive belt in the drive pulley, then in the driven pulley starting from the bottom.



mnr2008-042-002

Install and adjust drive belt, refer to *DRIVE BELT INSTALLATION AND ADJUSTMENT*.


### Drive Belt Installation and Adjustment

**NOTE:** The drive belt adjustment must be checked by an authorized SKI-DOO dealer each time a drive belt is installed and should be rechecked after 50 km (30 miles).

The maximum drive belt life span is obtained when the arrow on the drive belt is directed toward the front of the vehicle. This will ensure that correct direction of rotation is respected.




mnr2008-042-002



mno2008-003-042

### SUSPENSION ADJUSTMENT TOOL


- Turn adjustment ring counterclockwise ( $\pm 1$  turn) then, manually rotate drive belt to position it properly between pulley sheaves. Repeat this procedure until drive belt cord reaches the edge of the driven pulley.



- Suspension adjustment tool
- Adjustment ring




**MANUALLY ROTATE DRIVE BELT**




- Drive belt cord flush with pulley edge

When the drive belt is properly adjusted, ensure that the swivel ring rest against the driven pulley cam. If not, turn adjustment ring clockwise to lean the swivel ring against the driven pulley cam.



**INCORRECT POSITION**

- Swivel ring
- Driven pulley cam
- Not in contact with driven pulley



**PROPER POSITION**

- Swivel ring
- Driven pulley cam
- In contact with driven pulley

**NOTICE** Overtightening swivel ring will modify drive belt adjustment and reduce drive belt life span.



- Swivel ring

Install drive belt.


- Tighten the lock nut using the following tools from the tool kit.



mnr2008-042-003\_a


**DRIVEN PULLEY**

1. Lock nut
2. Adjustment ring




mno2008-003-043

**INSERT TOOL**



mno2008-003-039

**SCREWDRIVER PIN**



mno2008-003-040


**WRENCH SOCKET 16/18 MM**

Insert the screwdriver pin into the 16 mm wrench socket.



mno2008-003-044\_b

**TURN TOOL CLOCKWISE**



mno2008-003-041\_a

1. 16 mm end
2. 18 mm end
3. Screwdriver pin

Insert and set the 18 mm socket end on the locking nut inside the adjustment ring.

4. Tighten the lock nut by turning the tool clockwise ( $\pm 4$  turns).

5. Reinstall belt guard, refer to *DRIVE BELT GUARD*.

6. Close LH side panel.

**NOTE:** This setting is correct as a preliminary adjustment for most models and belt types. In some cases, when starting the engine, the vehicle could creep, indicating that the belt is too tight.

If the vehicle creeps, lower the belt, install the belt guard and side panel, then start engine. Repeat until creeping stops.

**NOTE:** After a drive belt replacement, have the tension checked by an authorized SKI-DOO dealer.

## Drive Belt Replacement (Screw Type Adjuster)

### Drive Belt Removal

1. Remove DESS key from post.
2. Open LH side panel, refer to *BODY*.
3. Remove belt guard, refer to *BELT GUARD REMOVAL*.
4. Insert the driven pulley expander provided in the tool box in the threaded hole on the adjuster hub as shown.



EXPANDER INSTALLED ON SCREW TYPE DRIVEN PULLEY


5. Open the driven pulley by screwing the tool in.
6. Remove the belt by slipping it over the top of the driven pulley, then over the drive pulley.

### Drive Belt Installation

1. If necessary, open the driven pulley, refer to *DRIVE BELT REMOVAL* above.
2. Slip the belt over the drive pulley, then over the driven pulley.

**NOTICE** Do not force or use tools to pry the belt into place, as this could cut or break the cords in the belt.

NOTE: The maximum drive belt life span is obtained when the arrow on the drive belt is directed toward the front of the vehicle. This will ensure that correct direction of rotation is respected.



1. Arrow pointing the front of vehicle

3. Unscrew and remove the driven pulley expander from the pulley.
4. Rotate the driven pulley several times to properly set the belt between the sheaves.
5. Install belt guard, refer to *DRIVE BELT GUARD INSTALLATION*.
6. Close side panel, refer to *BODY*.
7. If a new belt was installed, adjust the belt height. Refer to *DRIVE BELT HEIGHT ADJUSTMENT* below.


### Drive Belt Height Adjustment (Screw Type Adjuster)

The drive belt height adjustment must be performed every time a new belt is installed.

To adjust the drive belt height, proceed as follows:

1. Remove DESS key from post.
2. Open LH side panel, refer to *BODY*.
3. Remove belt guard, refer to *DRIVE BELT GUARD REMOVAL*.

- Keep the set screws from turning using a 3 mm Allen key and loosen both lock nuts using a 10 mm open wrench.




**LOOSEN THE LOCK NUTS**

- 3 mm Allen key
- 10 mm open wrench


- Turn one set screw 1/4 turn at a time then rotate the driven pulley to properly set the belt between the pulley sheaves. Repeat until the belt cord reaches the edge of the driven pulley.

**NOTE:** Turning the set screws clockwise lowers the belt in the pulley. Turning the set screws counterclockwise raises the belt in the pulley.



- Drive belt cord flush with pulley edge

- Set the other set screw so that it rests on the steel ring.



- Set screw
- Lock nut
- Steel ring

- Keep the set screws from turning and tighten the lock nuts towards the adjuster hub to 5 N•m (44 lbf•in)
- Install belt guard, refer to *DRIVE BELT GUARD INSTALLATION*.
- Close side panel, refer to *BODY*.

**NOTE:** This setting is correct as a preliminary adjustment for most models and belt types. In some cases, when starting the engine, the vehicle could creep, indicating that the belt is too tight.

If the vehicle creeps, lower the belt, install the belt guard and side panel, then start engine. Repeat until creeping stops.


**Spare Drive Belt Holder**

A spare drive belt can be stored in holder.

**NOTE:** Spare drive belt is not supplied with the snowmobile.


Properly install spare belt and secure with Velcro strap as shown.

**NOTICE** To avoid damages to the drive belt, ensure that belt does not come in contact with tuned pipe when installed in its support.




**WRONG INSTALLATION**

1. Drive belt in contact with tuned pipe



**INSTALLED CORRECTLY**

1. Drive belt over bumper
2. Ensure there is no contact with tuned pipe



**SECURE WITH VELCRO STRAP**

**Drive Pulley**

**Drive Pulley Adjustment**

**⚠ WARNING**

Remove the tether cord cap (DESS key) before performing any adjustment. Vehicle must be parked in a safe place, away from the trail.

The drive pulley is factory calibrated to transmit maximum engine power at a predefined RPM. Factors such as ambient temperature, altitude or surface condition may vary this critical engine RPM thus affecting snowmobile efficiency.

This adjustable drive pulley allows setting maximum engine RPM to maintain maximum power.


Calibration screws should be adjusted so that actual maximum engine RPM matches the maximum horsepower RPM.

ENGINE	MAXIMUM HORSEPOWER RPM
500SS	8000 RPM (± 100)
600 HO E-TEC	8100 RPM (± 100)
800R	8150 RPM (± 100)

**NOTE:** Use precision digital tachometer for engine RPM adjustment.

**NOTE:** The adjustment has an effect on high RPM only.

Calibration screw has a notch on top of its head.



**TYPICAL**

1. Notch

There are 6 positions numbered 1 to 6. Each position modifies maximum engine RPM by about 200 RPM.

Lower position numbers decrease engine RPM in steps of 200 RPM and higher position numbers increase it in steps of 200 RPM.


Example:

Calibration screw is set at position 4 and is changed to position 6. So maximum engine RPM is increased by 400 RPM.

**Procedure**

Just loosen locking nut enough to pull calibration screw partially out and adjust to desired position. Do not completely remove the locking nut. Torque locking nuts to 10 N•m (89 lbf•in).

**NOTICE** Do not completely remove calibration screw otherwise internal washers will fall off. Always adjust all 3 calibration screws and make sure they are all set to the same position.



**TYPICAL**  
1. Loosen just enough to permit rotating of calibrate screw

**⚠ WARNING**

NEVER disassemble or modify the drive pulley. Improper assembly or modifications could cause the pulley to explode violently under the stress generated by the high rotational speed. This could lead to serious injury including the possibility of death. See your SKI-DOO dealer to maintain or service the drive pulley. Improper servicing or maintenance may affect performance and reduce belt life. Always respect maintenance schedules.

**⚠ WARNING**

NEVER operate engine:

- Without shields and belt guard securely installed.
- With hood and/or side panels opened or removed.

NEVER attempt to make adjustments to moving parts while engine is running.

**Track**

**Track Condition**

**⚠ WARNING**

Remove the tether cord cap (DESS key) before performing any maintenance or adjustment, unless otherwise specified. Vehicle must be parked in a safe place, away from the trail.

Remove the tether cord cap (DESS key).

Lift the rear of the snowmobile and support it with a wide-base snowmobile mechanical stand with a rear deflector panel. With the engine off, rotate the track by hand, and inspect condition. If worn or cut, or if track fibers

are exposed, or if missing or defective inserts or guides are noted; contact an authorized SKI-DOO dealer.

### *Snowmobiles Equipped with Traction Enhancing Products*

If your snowmobile is equipped with a BRP approved studded track, PROCEED WITH A VISUAL INSPECTION OF YOUR TRACK BEFORE EACH USE.

Look for any defects, such as:

- Perforations in the track
- Tears in the track (particularly around traction holes on studded tracks)
- Lugs that are broken or torn off, exposing portions of rods
- Delamination of the rubber
- Broken rods
- Broken studs (studded tracks)
- Bent studs (studded tracks)
- Missing studs
- Studs that are torn off the track
- Missing track guide(s)
- Also, ensure that studs nut are tightened to the recommended torque.

On approved studded tracks, replace broken or damaged studs immediately. If your track shows signs of deterioration, it must be replaced immediately. When in doubt, ask your dealer.

**⚠ WARNING**

**Riding with a damaged track or studs could lead to a loss of control, resulting in a risk of serious injury or death.**

For complete information on traction enhancing products, refer to the section entitled *TRACTION ENHANCING PRODUCTS* in the *SAFETY INFORMATION* section at the beginning of this Operator's Guide.

## **Track Tension and Alignment**

**NOTE:** Track tension and alignment are interrelated. Do not adjust one without the other.

**⚠ WARNING**

**To prevent serious injury to individuals near the snowmobile:**

- NEVER stand behind or near a moving track.
- Always use a wide-base snowmobile stand with a rear deflector panel.
- When the track is raised off the ground, only run it at the lowest possible speed.

**Centrifugal force could cause debris, damaged or loose studs, pieces of torn track, or an entire severed track to be violently thrown backwards out of the tunnel with tremendous force, possibly resulting in the loss of a leg or other serious injury.**

## **Tension**

**NOTE:** Ride the snowmobile in snow about 15 to 20 minutes prior to adjusting track tension.


Remove the tether cord cap (DESS key).

Lift rear of snowmobile and support it with a wide-base snowmobile mechanical stand.


Allow the suspension to extend normally and check gap halfway between front and rear idler wheels. Measure between slider shoe bottom and inside of track. The gap should be as given in *SPECIFICATIONS* at the end of this guide. If the track tension is too loose, track will have a tendency to thump.

**NOTE:** A belt tension tester (P/N 414 348 200) may be used to measure deflection as well as force applied.





**BELT TENSION TESTER**



**TYPICAL**


1. Top tool O-ring positioned at 7.3 kg (16 lb)
2. Push on top portion of tool until it contacts the top O-ring
3. Measured track deflection

**NOTICE** Too much tension will result in power loss and excessive stresses on suspension components.

To adjust track tension:

- Remove the tether cord cap (DESS key).
- Remove rear wheel caps (if so equipped).
- Loosen the rear idler wheel retaining bolts.
- Turn adjustment bolts to adjust.

If correct tension is unattainable, contact an authorized SKI-DOO dealer.



**TYPICAL**

1. Adjustment bolts
2. Loosen bolt

1. Retighten retaining bolts.
2. Check track alignment as described below.

**Alignment**


**⚠ WARNING**

Before checking track alignment, ensure that the track is free of all particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Always lift the snowmobile on a wide-base stand with a rear deflector panel. Ensure no one is standing in close proximity to the snowmobile, especially at the rear of the track. Never rotate track at high speed.

Centrifugal force could cause debris, damaged or loose studs, pieces of torn track, or an entire severed track to be violently thrown backwards out of the tunnel with tremendous force, possibly resulting in the loss of a leg or other serious injury.

Start the engine and accelerate slightly so that track barely turns. This must be done in a short period of time (about 5 seconds).

Check that the track is well centered; equal distance on both sides between edges of track guides and slider shoes.




1. Guides
2. Slider shoes
3. Equal distance

If off center, perform alignment as follows:

### **⚠ WARNING**

Remove the tether cord cap (DESS key) before performing any maintenance or adjustment, unless otherwise specified. Vehicle must be parked in a safe place, away from the trail.

1. Remove the tether cord cap (DESS key).
2. Loosen rear idler wheel retaining bolts.
3. Tighten the adjustment bolt on side where the slider shoe is the farthest from the track insert guides.




1. Guides
2. Slider shoes
3. Tighten on this side

4. Tighten retaining bolts.

### **⚠ WARNING**

Properly tighten wheel retaining bolts, otherwise wheel may come off and cause track to "lock".



### TYPICAL

1. Retighten to 48 N•m (35 lbf•ft)
5. Restart engine and rotate track slowly to recheck alignment.
6. Reposition snowmobile on ground.
7. Install rear wheel caps if so equipped.

## Suspension

### Rear Suspension Condition

Visually inspect all suspension components including slider shoes, springs, wheels, etc.


**NOTE:** During normal driving, snow will act as a lubricant and coolant for the slider shoes. Extensive riding on ice or sanded snow, will create excessive heat build-up and cause premature slider shoe wear.

### Suspension Stopper Strap Condition


Inspect stopper strap for wear and cracks, bolt and nut for tightness. If loose inspect holes for deformation. Replace as required. Torque nut to 11 N•m (97 lbf•in).

### Rear Arm Lubrication


Lubricate rear arm at grease fittings using suspension synthetic grease (P/N 293 550 033). Refer to *MAINTENANCE SCHEDULE* for maintenance frequency.



MX Z X, MX Z TNT AND GSX SERIES  
1. Grease fittings



MX Z ADRENALINE, MX Z TRAIL,  
RENEGADE AND GTX SERIES  
1. Grease fittings



SUMMIT SERIES  
1. Grease fittings

## Steering and Front Suspension Condition

Visually inspect steering and front suspension for tightness of components (steering arms, control arms and links, tie rods, ball joints, ski bolts, ski legs, etc.). If necessary, contact an authorized SKI-DOO dealer.

## Skis

### Wear and Condition of Skis and Runners

Check the condition of the skis and ski runner carbides. If worn, contact an authorized SKI-DOO dealer.

### **⚠ WARNING**

Excessively worn skis and/or ski runners will adversely affect snowmobile control.


## Fuses

### Fuse Inspection

The electrical system is protected with fuses, refer to *MAINTENANCE INFORMATION* for details.

Check fuse condition and replace it if necessary.

To remove fuse from holder, pull fuse out. Check if filament is melted.



1. Fuse
2. Check if melted


**NOTICE** Do not use a higher rated fuse as this can cause severe damage to electrical components and/or be a potential fire.

### **⚠ WARNING**

If fuse has burnt out, source of malfunction should be determined and corrected before restarting. See an authorized SKI-DOO dealer for servicing.

## Fuse Location


### 500SS/800R Manual Start



#### RH SIDE OF ENGINE COMPARTMENT

1. 15 A headlight fuse (RED/ORANGE wire)
2. 15 A accessories fuse (RED/YELLOW wire)

### 500SS/800R Electric Start



#### RH SIDE OF ENGINE COMPARTMENT

1. 15 A headlight fuse (RED/ORANGE wire)
2. 15 A accessories fuse (RED/YELLOW wire)
3. 30 A charging system fuse
4. 5 A ECM (Engine Control Module) fuse

### 600 HO E-TEC Manual Start



#### TYPICAL - RH SIDE OF ENGINE COMPARTMENT

1. 5 A start/RER fuse

### 600 HO E-TEC Electric Start




#### TYPICAL - RH SIDE OF ENGINE COMPARTMENT

1. 30 A charging system fuse
2. 5 A start/RER fuse

### All Models

The electric fuel level sender fuse is located behind the air intake silencer.



#### BEHIND AIR INTAKE SILENCER

1. Fuse location

## Lights

Always check light operation after bulb replacement.

### Headlights Bulb Replacement

**NOTICE** Never touch glass portion of an halogen bulb with bare fingers, it shortens its operating life. If glass is touched, clean it with isopropyl alcohol which will not leave a film on the bulb.


1. By using a small screwdriver, release multifunction gauge locking tabs.



1. *Locking tab*
2. Gently pull on multifunction gauge and set aside.




3. Unplug burnt bulb connector. Remove the rubber boot.




1. *Rubber boots*

4. Press and pull both sides of the retaining clip at the same time to release it from bulb support.



- Step 1: *Push both sides*
- Step 2: *Pull to release*


1. *Retaining clip*
5. Pull bulb and replace. Properly reinstall parts.



**PULL BULB AND REPLACE**

### Headlights Beam Aiming

Remove multifunction gauge, refer to **HEADLIGHTS BULB REPLACEMENT**. Turn knob to adjust beam height.



**TYPICAL**  
1. Knobs


### Taillight Bulb Replacement

If taillight bulb is burnt, expose the bulb by removing the red plastic lens. To remove, unscrew the 2 lens screws.

### Body

#### Hood

To open hood, release hood retaining pins then slide hood towards the front of the vehicle.




Step 1: Release retaining pins  
Step 2: Slide hood towards the front

**⚠ WARNING**  
Never operate engine with hood removed from vehicle.

#### Side Panels

To open a side panel, stretch and unhook the latches.



**TYPICAL**  
1. Latches

To remove a side panel, open it then lift it up. Free the lower hinge from its slot, then free the upper hinge by lowering the panel.

**⚠ WARNING**  
Never operate engine with side panels opened or removed from vehicle.

### Vehicle Cleaning and Protection

Remove any dirt or rust.

To clean the entire vehicle, use only flannel cloths or equivalent.

**NOTICE** It is necessary to use flannel cloths or equivalent on windshield and hood to avoid damaging further surfaces to clean.

To remove grease, oil and grime, use Heavy duty cleaner (P/N 293 110 001) (spray can 400 g) and (P/N 293 110 002) (4 L).

**NOTICE** Do not use Heavy duty cleaner on decals or vinyl.

To remove stubborn dirt from all plastic and vinyl surfaces, use Vinyl & Plastic Cleaner ((P/N 413 711 200) (6 x 1 L)).

To remove scratches on windshield or hood use the Scratch Remover Kit (P/N 861 774 800).

**NOTICE** Never clean plastic parts or hood with strong detergent, degreasing agent, paint thinner, acetone, products containing chlorine, etc.

Wax painted portion of the vehicle for better protection.

**NOTE:** Apply wax on glossy finish only.

# STORAGE AND PRESEASON PREPARATION

## **⚠ WARNING**

Have an authorized SKI-DOO dealer inspect fuel and oil systems integrity as specified in *MAINTENANCE SCHEDULE*.

## **Storage**

During summer, or when a snowmobile is not in use for more than three months, proper storage is a necessity.

To prepare your snowmobile, refer to an authorized SKI-DOO dealer.

To facilitate the inspection and ensure adequate lubrication of components, it is recommended to clean the entire vehicle.

When storage procedure is completed, block muffler with clean rags.

Lift rear of vehicle until track is clear of the ground. Install on a wide-base snowmobile mechanical stand with a rear deflector panel.

## **⚠ WARNING**

Do not attempt to lift the vehicle by hand alone. Use appropriate lifting device or have assistance to share lifting stress in order to avoid risk of strain injuries.

**NOTE:** Do not release track tension.

Protect the vehicle with an approved cover to prevent dust accumulation during storage.

**NOTICE** The snowmobile has to be stored in a cool and dry place and covered with an opaque but ventilated tarpaulin. This will prevent sun rays and grime from affecting plastic components and vehicle finish.

## **Engine Storage Mode**


### *600 HO E-TEC Engines*

Like other engines, the 600 HO E-TEC has to be properly lubricated at storage for internal parts protection. The

E-TEC system offers a built-in engine lubrication function can be initiated by the operator.

To engage procedure, do the following:

1. Place the vehicle in a well ventilated area.
2. Start the engine and let it run at idle speed until it reaches its operating temperature (watch the coolant temperature on the display).
3. Push the SET (S) button to select odometer mode.




**NOTE:** The storage mode does not function in other modes (trip A, trip B and hr trip).

4. Press and hold the SET (S) button and simultaneously depress the HI/LOW beam switch repeatedly several times.
5. Release switch and button when **PUSH "S"** appears in the display.



6. Again, press and hold the SET (S) button 2 - 3 seconds.
7. When **OIL** appears in display, release the button and wait the end of the procedure.





The engine lubrication procedure takes approximately 1 minute. During this time the engine RPM will increase slightly.

At the end of engine lubrication procedure, the ECM will turn the engine off.

Remove tether cord.

**NOTICE** Do not start the engine during storage period.

### **Preseason Preparation**

To prepare your snowmobile, refer to an authorized SKI-DOO dealer.

**NOTICE** On 500SS and 800R engines, have carburetors cleaned-up before restarting engine.




# ***TECHNICAL INFORMATION***

# VEHICLE IDENTIFICATION

## Vehicle Description Decal

Vehicle description decal is located on right hand side of tunnel.



### TYPICAL

1. Vehicle description decal


note of all the serial numbers on your snowmobile and supply them to your insurance company.

## Vehicle Identification Number (V.I.N.) Location

V.I.N. is scribed on vehicle description decal. See above. It is also engraved on tunnel near vehicle description decal.

## Model Number Location

Model number is part of vehicle identification number (V.I.N.).



### V.I.N. DESCRIPTION

## Engine Serial Number Location



### TYPICAL - 500SS/600 HO E-TEC ENGINES


1. Engine serial number

## VEHICLE DESCRIPTION DECAL

1. Manufacturer name
2. Manufacturing date
3. Vehicle identification number (V.I.N.)
4. Model name
5. Option package
6. Engine type
7. Model year
8. Color codes
9. Vehicle weight/engine power (European models)

## Serial Numbers

The main components of your snowmobile (engine and frame) are identified by different serial numbers. It may sometimes become necessary to locate these numbers for warranty purposes or to trace your snowmobile in the event of loss. These numbers are required by the authorized SKI-DOO dealer to complete warranty claims properly. No warranty will be allowed by BRP if the engine serial number or vehicle identification number (V.I.N.) is removed or mutilated in any way. We strongly recommend that you take



### 800R POWER TEK ENGINE

1. Engine serial number

The EC-Declaration of Conformity does not appear in this version of the Operator's Guide.

Please refer to the printed version that was delivered with your vehicle.

---

# EPA CERTIFIED ENGINES

Maintenance, replacement, or repair of the emission control devices and systems may be performed by any snowmobile SI (spark ignition) engine repair establishments or individual.

## Engine Emissions Information

### Manufacturer's Responsibility

Beginning with 2009 model year engines, snowmobile manufacturers of snowmobile engines need to determine the exhaust emission levels for each engine horsepower family and certify these engines with the United States of America Environmental Protection Agency (EPA). An emissions control information label, showing emission levels and engine specifications, must be placed on each vehicle at the time of manufacture.

### Dealer's Responsibility

When performing service on a certified SKI-DOO snowmobiles that carry an emissions control information label, adjustments must be kept within published factory specifications.

Replacement or repair of any emission related component must be executed in a manner that maintains emission levels within the prescribed certification standards.

Dealers are not to modify the engine in any manner that would alter the horsepower or allow emission levels to exceed their predetermined factory specifications.

Exceptions include manufacturer's prescribed changes, such as altitude adjustments for example.

### Owner Responsibility

The owner/operator is required to have engine maintenance performed to maintain emission levels within prescribed certification standards.

The owner/operator is not to, and should not allow anyone to modify the engine in any manner that would alter the horsepower or allow emissions levels to exceed their predetermined factory specifications.

### EPA Emission Regulations

All 2009 SKI-DOO snowmobiles manufactured by BRP are certified to the EPA as conforming to the requirements of the regulations for the control of air pollution from new snowmobile engines. This certification is contingent on certain adjustments being set to factory standards. For this reason, the factory procedure for servicing the product must be strictly followed and, whenever practicable, returned to the original intent of the design.

The responsibilities listed above are general and in no way a complete listing of the rules and regulations pertaining to the EPA requirements on exhaust emissions for snowmobile products. For more detailed information on this subject, you may contact the following locations:

#### MAIL:

U.S. Environmental Protection Agency  
Office of Transportation and Air Quality  
1200 Pennsylvania Ave. NW  
Mail Code 6403J  
Washington D.C. 20460

#### INTERNET WEB SITE:

[www.epa.gov/otaq/](http://www.epa.gov/otaq/)

# SPECIFICATIONS

## 500SS Models

MODEL		500SS
<b>ENGINE</b>		
Engine type	Rotax 593, liquid cooled w/Reed valve, RAVE	
Cylinders	2	
Displacement	cc (in <sup>3</sup> )	597 (36.4)
Bore	mm (in)	76 (3)
Stroke	mm (in)	65.8 (2.6)
Maximum horsepower RPM	8000 RPM	
Carburetion	2 x TM-40	
Exhaust system	Single tuned pipe, baffle muffler	
<b>DRIVE SYSTEM</b>		
Drive pulley type	TRA III	
Driven pulley type	QRS	
Engagement	GSX/GTX	3400 RPM
	MX Z	3800 RPM
	Summit	4100 RPM
Small sprocket number of teeth	GSX	24
	GTX/MX Z (Europe)	23
	MX Z	25
	Summit	23
Large sprocket number of teeth	Summit	49
	Others	45
Drive sprocket number of teeth	8	
Brake system	Hydraulic, REV-XP brake type	
Track nominal width	381 mm (15 in)	
Track nominal length	MX Z/GSX	3051 mm (120 in)
	GTX	3487 mm (137 in)
	Summit	3705 mm (146 in)
Track profile height	MX Z/GSX/GTX	25.4 mm (1 in)
	MX Z TNT (Europe)	31.8 mm (1.25 in)
	Summit	50.8 mm (2.0 in)

**SPECIFICATIONS**

MODEL		500SS
<b>DRIVE SYSTEM (CONT'D)</b>		
Track tension	Deflection	30-35 mm (1-3/16 - 1-3/8 in)
	Force <sup>(1)</sup>	7.3 kg (16 lb)
Track alignment		Equal distance between edges of track guides and slider shoes
<b>SUSPENSION</b>		
Front suspension		REV-XP
Front shock	GSX/MX Z Trail/ Summit/GTX	Motion control
	MX Z TNT	Can/US: HPG T/A aluminum/Europe: HPG clicker T/A aluminum
	Others	HPG
Front suspension max. travel		229 mm (9 in)
Rear suspension	Summit	SC-5 M
	Others	SC-5
Front arm shock	GSX/MX Z Trail/ Summit/GTX	Motion control
	MX Z TNT	Can/US: HPG T/A aluminum/Europe: HPG T/A aluminum racing clicker
	Summit (Europe)	HPG
Rear arm shock	GSX/MX Z Trail/ Summit	Motion control
	MX Z TNT	Can/US: HPG T/A aluminum/Europe: HPG T/A aluminum racing clicker
	GTX	HPG VR
	Summit (Europe)	HPG
Rear suspension max. travel		381 mm (15 in)
<b>ELECTRICAL SYSTEM</b>		
Lightning system output		360 Watts @ 6000 RPM
Headlights bulb HI/LOW beam		2 x 60/55 Watts (H-4)
Taillight bulb		5/21
Spark plug	Type	NGK BR10ECS <sup>(2)</sup>
	Gap	Not adjustable (0.75 ± 0.05 mm (.030 ± .002 in))
Fuse		Refer to <i>FUSES</i> section



MODEL		500SS
<b>DIMENSIONS</b>		
Vehicle overall length	GSX/MX Z	2890 mm (113.8 in)
	GTX	3110 mm (122.4 in)
	Summit	3200 mm (126 in)
Vehicle overall width	MX Z/GSX/GTX/ Summit	1217 mm (47.9 in)
Dry weight	GSX Sport	198 kg (437 lb)
	MX Z TNT	181 kg (399 lb)
	MX Z Trail	188 kg (415 lb)
	Summit	193 kg (425 lb)
	GTX	211 kg (465 lb)
Ski stance	Summit	1138 to 1179 mm (44.8 to 46.4 in)
	Others	1195 mm (47 in)
Ski width	MX Z/GSX/GTX	145 mm (5.7 in)
	Summit	175 mm (6.9 in)
<b>FLUIDS</b>		
Recommended fuel type		Regular unleaded
Minimum octane	Inside North America	(87 (RON + MON)/2)
	Outside North America	92 RON
Recommended oil (engine)		XP-S Synthetic Blend 2-stroke oil (P/N 293 600 101)
Brake system fluid		GTLMA (DOT 4)
Oil type (chaincase)		XP-S synthetic chaincase oil
Coolant		Ethyl glycol/water mix (50% coolant, 50% distilled water). Use BRP premix coolant or coolant specifically designed for aluminum engines
<b>CAPACITIES</b>		
Fuel tank	L (U.S. gal)	40 (10.6)
Oil tank	L (U.S. quarts)	3.7 (3.9)

(1) Measure gap between slider shoe and bottom inside track when exerting a downward pull to the track.

(2) **NOTICE** Do not attempt to adjust gap on this spark plug.

**600 HO E-Tec Models**

MODEL		600 HO E-TEC
<b>ENGINE</b>		
Engine type		Rotax 593, liquid cooled w/Reed valve, 3D-RAVE
Cylinders		2
Displacement	cc (in <sup>3</sup> )	594.4 (36.3)
Bore	mm (in)	72 (2.8)
Stroke	mm (in)	73 (2.9)
Maximum engine speed		8100 RPM
Fuel injection system		E-TEC Direct injection
Exhaust system		Single tuned pipe, baffle muffler
<b>DRIVE SYSTEM</b>		
Drive pulley type		TRA III
Driven pulley type		QRS
Engagement	Summit	4000 RPM
	Others	3400 RPM
Small sprocket number of teeth	All Renegade	21
	Summit	19
	Others	25
Large sprocket number of teeth	Summit	49
	Others	45
Drive sprocket number of teeth		8
Brake system		Hydraulic, REV-XP brake type
Track nominal width	All Renegade/Summit	406 mm (16 in)
	Others	381 mm (15 in)
	All Renegade/ Adrenaline (Europe)	3487 mm (137 in)
Track nominal length	Summit	3705 mm (146 in)
		3923 mm (154 in)
	Others	3051 mm (120 in)

MODEL		600 HO E-TEC
<b>DRIVE SYSTEM (CONT'D)</b>		
Track profile height	MX Z X (Can/US)/ Renegade	31.8 mm (1.25 in)
	MX Z X TNT (European model)/ Adrenaline (European model)	31.8 mm (1.25 in)
	Summit	57.15 mm (2.25 in)
	Others	25.4 mm (1 in)
Track tension	Deflection	30-35 mm (1-3/16 - 1-3/8 in)
	Force <sup>(1)</sup>	7.3 kg (16 lb)
Track alignment		Equal distance between edges of track guides and slider shoes
<b>SUSPENSION</b>		
Front suspension		REV-XP
Front shock	MX Z TNT (Can/US)/ 50 <sup>th</sup> anniversary/ Summit X	HPG T/A aluminum
	MX Z X/Renegade X/ MX Z TNT (European model)	HPG clicker T/A aluminum
	Others	HPG
Front suspension max. travel		229 mm (9 in)
Rear suspension	Summit	SC-5 M
	Others	SC-5
Front arm shock	MX Z X/Renegade X/ TNT (Can/US)/ 50 <sup>th</sup> anniversary/ Summit X	HPG T/A aluminum
	Others	HPG
Rear arm shock	GSX	HPG-VR
	MX Z TNT (Can/US)/ 50 <sup>th</sup> anniversary/ Summit X	HPG T/A aluminum
	MX Z X/Renegade X/ TNT (Europe)	Racing clicker aluminum
	Others	HPG
Rear suspension max. travel	All Renegade	406 mm (16 in)
	Others	381 mm (15 in)

**SPECIFICATIONS**

MODEL		600 HO E-TEC
<b>ELECTRICAL SYSTEM</b>		
Lightning system output		12V/360 W 55 V/1100 W
Headlights bulb HI/LOW beam		2 x 60/55 Watts (H-4)
Taillight bulb		521
Spark plug	Type	NGK PZFR6F <sup>(2)</sup>
	Gap	Not adjustable 0.8 + 0 mm/- 0.1 mm (.031 + 0 in/- .004 in)
Fuse		Refer to <i>FUSES</i> section
<b>DIMENSIONS</b>		
Vehicle overall length	All Renegade/ Adrenaline (Europe)	3110 mm (122.4 in)
	Summit	3200 mm (126 in)/(146 in)
		3310 mm (130.3 in)/(154 in)
	Others	2890 mm (113.8 in)
Vehicle overall width		1217 mm (47.9 in)
Dry weight	GSX Limited	204 kg (448 lb)
	MX Z Adrenaline	193 kg (425 lb)
	MX Z Renegade/ Summit 146 in	197 kg (435 lb)
	MX Z Renegade X	194 kg (4270 lb)
	MX Z X	188 kg (415 lb)
	Summit (154 in)	191 kg (422 lb)
Ski stance	Summit (Except HillClimb Edition)	1138 to 1179 mm (44.8 to 46.4 in)
	Summit HillClimb Edition	1036 to 1080 mm (40.8 to 42.5 in)
	Others	1195 mm (47 in)
Ski width	Summit	175 mm (6.9 in)
	Others	145 mm (5.7 in)

MODEL		600 HO E-TEC
<b>FLUIDS</b>		
Recommended fuel type		Premium unleaded
Minimum octane	Inside North America	(91 (RON + MON)/2)
	Outside North America	95 RON
Recommended oil (engine)		XP-S Synthetic Blend 2-stroke oil (P/N 293 600 101)
Brake system fluid		GTLM (DOT 4)
Oil type (chaincase)		XP-S synthetic chaincase oil
Coolant		Ethyl glycol/water mix (50% coolant, 50% distilled water). Use BRP premix coolant or coolant specifically designed for aluminum engines
<b>CAPACITIES</b>		
Fuel tank	L (U.S. gal)	40 (10.6)
Oil tank	L (U.S. quarts)	3.7 (3.9)

(1) Measure gap between slider shoe and bottom inside track when exerting a downward pull to the track.

(2) **NOTICE** Do not attempt to adjust gap on this spark plug.

**800R Models**

MODEL		800R
<b>ENGINE</b>		
Engine type	Rotax 797, Power TEK, liquid cooled, 3-D RAVE	
Cylinders	2	
Displacement	cc (in <sup>3</sup> )	799.5 (48.8)
Bore	82 mm (3.2 in)	
Stroke	75.7 mm (3.0 in)	
Maximum engine speed	8150 RPM	
Carburetion	2 x TM-40	
Exhaust system	Single tuned pipe, baffle muffler	
<b>DRIVE SYSTEM</b>		
Drive pulley type	TRA VII	
Driven pulley type	QRS	
Engagement	3800 RPM	
Small sprocket number of teeth	MX Z	27
	Renegade (Can/US)	25
	Renegade (Europe)	23
	Summit	21
Large sprocket number of teeth	Summit (163 in)	49
	Others	45
Drive sprocket number of teeth	8	
Brake system	Hydraulic, REV-XP brake type	
Track nominal width	All Renegade/ Summit	406 mm (16 in)
	Others	381 mm (15 in)
Track nominal length	All Renegade	3487 mm (137 in)
	Summit	3705 mm (146 in)
		3923 mm (154 in)
		4141 mm (163 in)
Others	3051 mm (120 in)	

MODEL		800R
<b>DRIVE SYSTEM (cont'd)</b>		
Track profile height	All Renegade	31.8 mm (1.25 in)
	MX Z X	31.8 mm (1.25 in)
	Summit	57.2 mm (2.25 in)
	Others	25.4 mm (1 in)
Track tension	Deflection	30-35 mm (1-3/16 - 1-3/8 in)
	Force <sup>(1)</sup>	7.3 kg (16 lb)
Track alignment		Equal distance between edges of track guides and slider shoes
<b>SUSPENSION</b>		
Front suspension		REV-XP
Front shock	MX Z X/Renegade X/ Summit HiilClimb	HPG clicker T/A aluminum
	Summit X/ 50 <sup>th</sup> anniversary	HPG T/A aluminum
	Others	HPG
Front suspension max. travel		229 mm (9 in)
Rear suspension	Summit	SC-5M
	Others	SC-5
Front arm shock	X package/ Summit HiilClimb/ Summit/ 50 <sup>th</sup> anniversary	HPG T/A aluminum
	Others	HPG
Rear arm shock	MX Z X/Renegade X/ Summit HiilClimb	Racing clicker T/A aluminum
	Summit X/ 50 <sup>th</sup> anniversary	HPG T/A aluminum
	Others	HPG
Rear suspension max. travel	All Renegade	406 mm (16 in)
	Summit	356 mm (14 in)/(146 in)
		381 mm (15 in)/(154 in)
		406 mm (16 in)/(163 in)
Others	381 mm (15 in)	

**SPECIFICATIONS**

MODEL		800R
<b>ELECTRICAL SYSTEM</b>		
Lightning system output		360 Watts @ 6000 RPM
Headlights bulb HI/LOW beam		2 x 60/55 Watts (H-4)
Taillight bulb		5/21
Spark plug	Type	NGK BR9ECS <sup>(2)</sup>
	Gap	Not adjustable (0.75 ± 0.05 mm (.030 ± .002 in))
Fuse		Refer to <i>FUSES</i> section
<b>DIMENSIONS</b>		
Vehicle overall length	All Renegade	3110 mm (122.4 in)
	Summit	3200 mm (126 in)/(146 in)
		3310 mm (130.3 in)/(154 in)
		3420 mm (134.6 in)/(163 in)
Others	2890 mm (113.8 in)	
Vehicle overall width	Summit	1163 to 1204 mm (45.8 to 47.4 in)
	Others	1217 mm (47.9 in)
Dry weight	MX Z Adrenaline	197 kg (435 lb)
	MX Z X	193 kg (425 lb)
	MX Z Renegade	202 kg (445 lb)
	MX Z Renegade X	198 kg (437 lb)
	Summit	197 kg (435 lb)/(146 in)
		200 kg (439 lb)/(154 in)
		201 kg (444 lb)/(163 in)
	Summit X	193 kg (425 lb)/(146 in)
		195 kg (429 lb)/(154 in)
197 kg (434 lb)/(163 in)		



MODEL		800R
<b>DIMENSIONS (cont'd)</b>		
Ski stance	Summit (except HillClimb Edition)	1138 to 1179 mm (44.8 to 46.4 in)
	Others	1195 mm (47 in)
Ski width	Summit	175 mm (6.9 in)
	Others	145 mm (5.7 in)
<b>FLUIDS</b>		
Recommended fuel type		Premium unleaded
Minimum octane	Inside North America	(91 (RON + MON)/2)
	Outside North America	95 RON
Recommended oil (engine)		XP-S Synthetic Blend 2-stroke oil (P/N 293 600 101)
Brake system fluid		GTLMA (DOT 4)
Oil type (chaincase/transmission)		XP-S synthetic chaincase oil
Coolant		Ethyl glycol/water mix (50% coolant, 50% distilled water). Use BRP premix coolant or coolant specifically designed for aluminum engines
<b>CAPACITIES</b>		
Fuel tank	L (U.S. gal)	40 (10.6)
Oil tank	L (U.S. quarts)	3.7 (3.9)

(1) Measure gap between slider shoe and bottom inside track when exerting a downward pull to the track.

(2) **NOTICE** Do not attempt to adjust gap on this spark plug.



# ***TROUBLESHOOTING***

---

# TECHNICAL GUIDELINES (500SS AND 800R)

---

## ENGINE IS CRANKED BUT FAILS TO START.

---

1. Engine stop switch is in OFF position or tether cord cap (DESS key) away from post.
  - Place engine stop switch in the ON position and install tether cord cap (DESS key) on post.
2. Mixture not rich enough to start cold engine.
  - Check fuel tank level and check starting procedure, particularly use of the choke.
3. Flooded engine (spark plug wet when removed).
  - Do not choke. Remove wet spark plug, place engine stop switch in OFF position and crank engine several times. Install clean dry spark plug.
  - Start engine following usual starting procedure. If engine continues to flood, see an authorized SKI-DOO dealer.
4. No fuel to the engine (spark plug dry when removed).
  - Check fuel tank level; check condition of fuel and impulse lines and their connections. A failure of the fuel pump or carburetor has occurred. Contact an authorized SKI-DOO dealer.
5. Spark plug/ignition (no spark).
  - Remove spark plug(s) then reconnect to spark cap. Check that engine stop switch is at the ON position and the tether cord cap (DESS key) snapped over the receptacle.
  - Start engine with spark plug(s) grounded to engine away from spark plug hole. If no spark appears, replace spark plug. If trouble persists, contact an authorized SKI-DOO dealer.
6. Engine compression.
  - As the engine is pulled over with the rewind starter, “cycles” of resistance should be felt as piston goes past top dead center (each piston on multi-cylinder engines).
  - If no pulsating resistance is felt, it suggests a major loss of compression. Contact an authorized SKI-DOO dealer.

---

## ENGINE LACKS ACCELERATION OR POWER.

---

1. DESS did not read tether cord cap (DESS KEY) code. DESS pilot lamp blinks once every 1.5 seconds. Engine can not exceed 3000 RPM.
  - Properly install tether cord cap (DESS key).
2. DESS has read a different code than the one programmed. DESS pilot lamp blinks rapidly (3 times per second). Engine can not exceed 3000 RPM.
  - Install a tether cord cap (DESS key) for which this snowmobile was programmed.
3. Fouled or defective spark plug.
  - Check item 5 of ENGINE TURNS OVER BUT FAILS TO START.
4. Lack of fuel to engine.
  - Check item 4 of ENGINE TURNS OVER BUT FAILS TO START.

---

**ENGINE LACKS ACCELERATION OR POWER. (cont'd)**

---

**5. Carburetor adjustments.**

- *Contact an authorized SKI-DOO dealer.*

**6. Drive belt worn too thin.**

- *If the drive belt has lost more than 3 mm (1/8 in) of its original width, it will affect vehicle performance.*
- *Replace drive belt.*

**7. Drive and driven pulleys require servicing.**

- *Contact an authorized SKI-DOO dealer.*

**8. Engine overheats.**

- *Check coolant level, see MAINTENANCE PROCEDURES.*
- *Check if heat exchangers cleanliness. Clean if necessary.*
- *If coolant level is correct and heat exchangers are clean, contact an authorized SKI-DOO dealer.*

---

**ENGINE BACKFIRES.**

---

**1. DESS did not read tether cord cap (DESS key) code. DESS pilot lamp blinks once every 1.5 seconds. Engine can not exceed 3000 RPM.**

- *Properly install tether cord cap (DESS key).*

**2. DESS has read a different tether cord cap (DESS key) code then the one programmed. DESS pilot lamp blinks rapidly (3 times per second). Engine can not exceed 3000 RPM.**

- *Install a tether cord cap (DESS key) for which this snowmobile was programmed.*

**3. Faulty spark plug (carbon accumulation).**

- *See item 5 of ENGINE TURNS OVER BUT FAILS TO START.*

**4. Engine is running too hot.**

- *See item 6 of ENGINE LACKS ACCELERATION OR POWER.*

**5. Ignition timing is incorrect or there is an ignition system failure.**

- *Contact an authorized SKI-DOO dealer.*

---

**ENGINE MISFIRES.**

---

**1. DESS did not read tether cord cap (DESS key) code. DESS pilot lamp blinks once every 1.5 seconds. Engine can not exceed 3000 RPM.**

- *Properly install tether cord cap (DESS key).*

**2. DESS has read a different code then the one programmed. DESS pilot lamp blinks rapidly (3 times per second). Engine can not exceed 3000 RPM.**

- *Install a tether cord cap (DESS key) for which this snowmobile was programmed.*

**3. Fouled/defective/worn spark plugs.**

- *Clean/verify spark plug gap and identification number. Replace as required.*

**4. Too much oil supplied to engine.**

- *Improve oil pump adjustment, refer to an authorized SKI-DOO dealer.*

**ENGINE MISFIRES. (cont'd)**

---

**5. Water in fuel.**

- *Drain fuel system and refill with fresh fuel.*

**SNOWMOBILE CANNOT REACH FULL SPEED.**

---

**1. Drive belt.**

- *Check item 6 of ENGINE LACKS ACCELERATION OR POWER.*

**2. Incorrect track adjustment.**

- *See MAINTENANCE PROCEDURES and/or an authorized SKI-DOO dealer for proper alignment and tension adjustments.*

**3. Pulleys misaligned.**

- *Contact an authorized SKI-DOO dealer.*

**4. Engine.**

- *See items 1, 2, 6 and 7 of ENGINE LACKS ACCELERATION OR POWER.*

---

# TECHNICAL GUIDELINES (600 HO E-TEC)

---

## ENGINE IS CRANKED BUT FAILS TO START.

---

1. Engine stop switch is in OFF position or tether cord cap (DESS key) away from post.
  - *Place engine stop switch in the ON position and install tether cord cap (DESS key) on post.*
2. No fuel to the engine.
  - *Check fuel tank level, add fuel if necessary.*

## ENGINE LACKS POWER AND CLUTCH DOES NOT ENGAGE.

---

1. DESS did not read tether cord cap (DESS key) code. DESS pilot lamp blinks (slow short beeps/repetitive). Engine can not exceed 3000 RPM.
  - *Properly install tether cord cap (DESS key).*
2. DESS has read a different code than the one programmed. DESS pilot lamp blinks rapidly (fast short beeps/repetitive). Engine can not exceed 3000 RPM.
  - *Install a tether cord cap (DESS key) for which this snowmobile was programmed.*
3. Drive belt worn too thin.
  - *If the drive belt has lost more than 3 mm (1/8 in) of its original width, it will affect vehicle performance.*
  - *Replace drive belt.*
4. Drive and driven pulleys require servicing.
  - *Contact an authorized SKI-DOO dealer.*
5. Engine overheats.
  - *Check coolant level, see MAINTENANCE PROCEDURES.*
  - *Check heat exchangers cleanliness. Clean if necessary.*
  - *If coolant level is correct and heat exchangers are clean, contact an authorized SKI-DOO dealer.*

## ENGINE BACKFIRES.

---

1. Engine is running too hot.
  - *See item 3 of ENGINE LACKS POWER AND CLUTCH DOES NOT ENGAGE.*
2. Ignition timing is incorrect or there is an ignition system failure.
  - *Contact an authorized SKI-DOO dealer.*

## ENGINE MISFIRES.

---

1. Water in fuel.
  - *Drain fuel system and refill with fresh fuel.*
2. RAVE valves malfunction.
  - *Have RAVE valves system inspect by an authorized SKI-DOO dealer.*

**SNOWMOBILE CANNOT REACH FULL SPEED.**

---

**1. Drive belt.**

- *Check item 3 of ENGINE LACKS POWER AND CLUTCH DOES NOT ENGAGE.*

**2. Incorrect track adjustment.**

- *See MAINTENANCE INFORMATION and/or an authorized SKI-DOO dealer for proper alignment and tension adjustments.*

**3. Engine.**

- *See items 1, 2, 3 and 4 of ENGINE LACKS POWER AND CLUTCH DOES NOT ENGAGE.*




---

# MONITORING SYSTEM

## Pilot Lamps, Messages and Beeper Codes


Gauge pilot lamp(s) will inform you if an anomaly occurs or to inform you of a particular condition.



TYPICAL — PILOT LAMPS

Pilot lamp can flash alone or in combination with another lamp.

This display is used as a complement of the pilot lamps to give you a brief description if an anomaly occurs or to inform you of a particular condition.








1. Message display


Messages will be displayed with a beep code and pilot lamp(s).

Beeper codes will be heard and messages (depending on gauge model) will be displayed to catch your attention.

See table below for details.

**NOTE:** Message display is not available on all gauges.

PILOT LAMP(S) ON	BEEPER	MESSAGE DISPLAY <sup>(1)</sup>	DESCRIPTION
	4 short beeps	ENGINE	Engine is overheating, reduce snowmobile speed and run in loose snow or stop engine immediately and let engine cool down. Check coolant level, refer to <i>MAINTENANCE INFORMATION</i> . If coolant level is correct and overheating persists, contact an authorized SKI-DOO dealer. Do not run the engine if condition persists.
		MUFFLER	Reduce speed or stop engine. Let engine cool down and restart. If overheating persists, contact an authorized SKI-DOO dealer. Do not run the engine if condition persists.
  	Short beeps repeating rapidly	ENGINE	Critical overheat. Stop engine immediately and let engine cool down. Check coolant level, refer to <i>MAINTENANCE INFORMATION</i> . If coolant level is correct and overheating persists, contact an authorized SKI-DOO dealer. Do not run the engine if condition persists.
		MUFFLER	Critical overheat. Stop engine immediately and let engine cool down. If overheating persists, contact an authorized SKI-DOO dealer. Do not run the engine if condition persists.
		ECM	
  	4 short beeps every 2 minutes	LOW BAT	Indicate a low or high battery voltage condition. See an authorized SKI-DOO dealer as soon as possible.
		HIGH BAT	

PILOT LAMP(S) ON	BEEPER	MESSAGE DISPLAY <sup>(1)</sup>	DESCRIPTION
	4 short beeps	CHECK ENGINE	Engine fault, see an authorized SKI-DOO dealer as soon as possible.
	4 short beeps every 2 minutes	KNOCK	Engine detonation (RPM is limited when this condition occurs). – Ensure recommended fuel is used. – Check fuel quality, replace if necessary. – If fault still occurs, contact an authorized SKI-DOO dealer.
	4 short beeps every 2 minutes	LIMP HOME	Engine RPM limited for protection when certain faults occur.
	Continuously beeps	SHUTDOWN	Shutdown procedure in force due to engine overheating or fuel pump problem, remove tether cord cap (DESS key) and contact an authorized SKI-DOO dealer.
—	—	COMMUNICATION	Communication problem between ECM and gauge. Stop engine, remove tether cord cap (DESS key). Wait a few minutes, then start engine. If problem persists, contact an authorized SKI-DOO dealer.
<b>DESS</b>	2 short beeps	—	Good key, vehicle ready to operate.
	2 short beeps, repeating slowly	CHECK KEY	Unable to read key (bad connection). Make sure the key is clean and correctly snapped on post.
	Short beeps repeating rapidly	BAD KEY	Invalid key or key not programmed. Use the proper key for the vehicle or have the programmed.

(1) 50<sup>th</sup> anniversary, X and Limited package only

## How to Read Fault Codes

### *Multifunction Analog/Digital Display Only*

Press and hold MODE (M) Button and simultaneously depress the HI/LOW beam switch repeatedly several times.

If two or more codes are registered, use SET (S) or MODE (M) to scroll.

To exit the fault codes mode, press and hold MODE (M) button.

Contact an authorized SKI-DOO dealer for code signification.



# ***WARRANTY***

---

# **BRP LIMITED WARRANTY USA AND CANADA: 2009 SKI-DOO® SNOWMOBILES**

## **1) SCOPE OF THE LIMITED WARRANTY**

Bombardier Recreational Products Inc. ("BRP")\* warrants its 2009 Ski-Doo snowmobiles sold by authorized BRP dealers (as hereinafter defined) in the fifty United States and Canada from defects in material or workmanship for the period and under the conditions described below. This limited warranty will become null and void if:

1. The snowmobile was used for racing or any other competitive activity, at any point, even by a previous owner; or
2. The snowmobile has been altered or modified in such a way so as to adversely affect its operation, performance or durability, or has been altered or modified to change its intended use.

All genuine Ski-Doo parts and accessories, installed by an authorized BRP dealer at the time of delivery of the 2009 Ski-Doo snowmobile, carry the same warranty as that of the snowmobile.

## **2) LIMITATIONS OF LIABILITY**

THIS WARRANTY IS EXPRESSLY GIVEN AND ACCEPTED IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT THAT THEY CANNOT BE DISCLAIMED, THE IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFE OF THE EXPRESS WARRANTY. INCIDENTAL AND CONSEQUENTIAL DAMAGES ARE EXCLUDED FROM COVERAGE UNDER THIS WARRANTY. SOME STATES/PROVINCES DO NOT ALLOW FOR THE DISCLAIMERS, LIMITATIONS AND EXCLUSIONS IDENTIFIED ABOVE, AS A RESULT, THEY MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH MAY VARY FROM STATE TO STATE, OR PROVINCE TO PROVINCE.

Neither the distributor, any BRP dealer nor any other person has been authorized to make any affirmation, representation or warranty regarding the product, other than those contained in this limited warranty, and if made, shall not be enforceable against BRP.

BRP reserves the right to modify this warranty at any time, being understood that such modification will not alter the warranty conditions applicable to the products sold while this warranty is in effect.

## **3) EXCLUSIONS – ARE NOT WARRANTED**

The following are not warranted under any circumstances:

- Normal wear and tear;
- Routine maintenance items, tune ups, adjustments;
- Damage caused by failure to provide proper maintenance and/or storage, as described in the Operator's Guide;
- Damage resulting from removal of parts, improper repairs, service, maintenance, modifications or use of parts not manufactured or approved by BRP or resulting from repairs done by a person that is not an authorized servicing BRP dealer;

- Damage caused by abuse, abnormal use, neglect, use of the product on surfaces other than snow, or operation of the product in a manner inconsistent with the recommended operation described in the Operator's Guide;
- Damage resulting from accident, submersion, fire, theft, vandalism or any act of God;
- Operation with fuels, oils or lubricants which are not suitable for use with the product (see the Operator's Guide);
- Snow or water ingestion;
- Incidental or consequential damages, or damages of any kind including without limitation towing, storage, telephone, rental, taxi, inconvenience, insurance coverage, loan payments, loss of time, loss of income; and
- Damage resulting from studs installed on tracks if the installation does not conform to BRP's instructions.

#### **4) WARRANTY COVERAGE PERIOD**

This warranty will be in effect from the date of delivery to the first retail consumer or the date the product is first put into use, whichever occurs first and for a period of:

TWELVE (12) CONSECUTIVE MONTHS, for private or commercial use owners. However, the warranty coverage period on a snowmobile delivered between June 1<sup>st</sup> and December 1<sup>st</sup> of a given year will expire November 30<sup>th</sup> of the following year.

The emission-related components included in the chart below, that are installed on EPA certified snowmobiles (see list below) registered in the USA are covered for thirty (30) consecutive months or 2500 miles (4000 km) of engine use whichever occurs first. If the 2500 miles (4000 km) are reached during the regular warranty coverage period, the emission-related components are still covered by BRP's standard warranty until the end of regular coverage period.

The SKI-DOO engines are all EPA certified. Refer to the following table for details regarding the emission related components covered by the EPA.

EMISSION-RELATED COMPONENTS	500SS	600 HO E-TEC	800R
Carburetor	X		X
Carburetor/Throttle Body Air Intake Adapter	X	X	X
Reed Valve	X	X	X
Rave Hose System		X	X
Throttle Position Sensor (TPS)		X	X
Air Temperature Sensor (ATS)		X	X
Air Pressure Sensor (APS)		X	X
Knock Sensor		X	X
Engine Control Module (ECM)		X	X
Fuel Pressure Regulator		X	
Fuel Injectors		X	
Muffler Temperature Sensor		X	
Coolant Temperature Sensor (CTS)			X
DPM Solenoid			X

The repair or replacement of parts or the performance of service under this warranty does not extend the life of this warranty beyond its original expiration date.

### 5) CONDITIONS TO HAVE WARRANTY COVERAGE

This warranty coverage is available **only** if each of the following conditions has been fulfilled:

- The 2009 Ski-Doo snowmobile must be purchased as new and unused by its first owner from a BRP dealer authorized to distribute Ski-Doo snowmobiles in the country in which the sale occurred ("BRP dealer");
- The BRP specified pre-delivery inspection process must be completed and documented;
- The product must have undergone proper registration by an authorized BRP dealer;
- The 2009 Ski-Doo snowmobile must be purchased in the country in which the purchaser resides;
- Routine maintenance outlined in the Operator's Guide must be timely performed in order to maintain warranty coverage. BRP reserves the right to make warranty coverage contingent upon proof of proper maintenance.

BRP will not honor this limited warranty to any private use owner or commercial use owner if the preceding conditions have not been met. Such limitations are necessary in order to allow BRP to preserve both the safety of its products, and also that of its consumers and the general public.



## **6) WHAT TO DO TO OBTAIN WARRANTY COVERAGE**

The customer must cease using the snowmobile upon the appearance of an anomaly. The customer must notify a servicing BRP dealer within two (2) days of the appearance of a defect, and provide it with reasonable access to the product and reasonable opportunity to repair it. The customer must also present to the authorized BRP dealer, proof of purchase of the product and must sign the repair/work order prior to starting the repair in order to validate the warranty repair. All parts replaced under this limited warranty become the property of BRP.

## **7) WHAT BRP WILL DO**

BRP's obligations under this warranty are limited to, at its sole discretion, repairing parts found defective under normal use, maintenance and service, or replacing such parts with new genuine Ski-Doo parts without charge for parts and labor, at any authorized BRP dealer during the warranty coverage period under the conditions described herein. BRP's responsibility is limited to making the required repairs or replacements of parts. No claim of breach of warranty shall be cause for cancellation or rescission of the sale of the snowmobile to the owner.

In the event that service is required outside of the country of original sale, the owner will bear responsibility for any additional charges due to local practices and conditions, such as, but not limited to, freight, insurance, taxes, license fees, import duties, and any and all other financial charges, including those levied by governments, states, territories and their respective agencies.

BRP reserves the right to improve or modify products from time to time without assuming any obligation to modify products previously manufactured.

## **8) TRANSFER**

If the ownership of a product is transferred during the warranty coverage period, this warranty shall also be transferred and be valid for the remaining coverage period provided that BRP is notified of such transfer of ownership in the following way:

1. The former owner contacts BRP (at the phone number provided below) or an authorized BRP dealer and gives the coordinates of the new owner; or
2. BRP or an authorized BRP dealer receives a proof that the former owner agreed to the transfer of ownership, in addition to the coordinates of the new owner.

## **9) CONSUMER ASSISTANCE**

In the event of a controversy or a dispute in connection with this limited warranty, BRP suggests that you try to resolve the issue at the dealership level. We recommend discussing the issue with the authorized dealer's service manager or owner.

If the issue has not yet been resolved, please submit your complaint in writing or call the appropriate number below:

### **In Canada**

**BOMBARDIER RECREATIONAL PRODUCTS INC.**

SKI-DOO

Customer Assistance Center

75, J.-A. Bombardier Street

Sherbrooke, Québec J1L 1W3

Tel.: 819 566-3366

### **In USA**

**BRP US INC.**

SKI-DOO

Customer Assistance Center

7575 Bombardier Court

Wausau WI 54401

Tel.: 715 848-4957

\* In the USA, products are distributed and serviced by BRP US Inc.

© 2008 Bombardier Recreational Products Inc. All rights reserved.

® Registered trademark of Bombardier Recreational Products Inc.

---

# **BRP INTERNATIONAL LIMITED WARRANTY: 2009 SKI-DOO® SNOWMOBILES**

## **1) SCOPE OF THE LIMITED WARRANTY**

Bombardier Recreational Products Inc. ("BRP")\* warrants its 2009 Ski-Doo snowmobiles sold by authorized BRP distributor/dealer (as hereinafter defined) outside of the fifty United States, Canada and states members of the European Economic Area ("EEA") (which is comprised of the states member of the European Union plus Norway, Iceland and Liechtenstein) from defects in material or workmanship for the period and under the conditions described below. This limited warranty will become null and void if:

1. The snowmobile was used for racing or any other competitive activity, at any point, even by a previous owner; or
2. The snowmobile has been altered or modified in such a way so as to adversely affect its operation, performance or durability, or has been altered or modified to change its intended use.

All genuine Ski-Doo parts and accessories, installed by an authorized BRP distributor/dealer at the time of delivery of the 2009 Ski-Doo snowmobile, carry the same warranty as that of the snowmobile.

## **2) LIMITATIONS OF LIABILITY**

THIS WARRANTY IS EXPRESSLY GIVEN AND ACCEPTED IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT THAT THEY CANNOT BE DISCLAIMED, THE IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFE OF THE EXPRESS WARRANTY. INCIDENTAL AND CONSEQUENTIAL DAMAGES ARE EXCLUDED FROM COVERAGE UNDER THIS WARRANTY. SOME STATES/PROVINCES DO NOT ALLOW FOR THE DISCLAIMERS, LIMITATIONS AND EXCLUSIONS IDENTIFIED ABOVE, AS A RESULT, THEY MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH MAY VARY FROM STATE TO STATE, OR PROVINCE TO PROVINCE.

Neither the distributor, any BRP distributor/dealer nor any other person has been authorized to make any affirmation, representation or warranty regarding the product, other than those contained in this limited warranty, and if made, shall not be enforceable against BRP.

BRP reserves the right to modify this warranty at any time, being understood that such modification will not alter the warranty conditions applicable to the products sold while this warranty is in effect.

## **3) EXCLUSIONS – ARE NOT WARRANTED**

The following are not warranted under any circumstances:

- Normal wear and tear;
- Routine maintenance items, tune ups, adjustments;
- Damage caused by failure to provide proper maintenance and/or storage, as described in the Operator's Guide;

- Damage resulting from removal of parts, improper repairs, service, maintenance, modifications or use of parts not manufactured or approved by BRP or resulting from repairs done by a person that is not an authorized servicing BRP distributor/dealer;
- Damage caused by abuse, abnormal use, neglect, use of the product on surfaces other than snow, or operation of the product in a manner inconsistent with the recommended operation described in the Operator's Guide;
- Damage resulting from accident, submersion, fire, theft, vandalism or any act of God;
- Operation with fuels, oils or lubricants which are not suitable for use with the product (see the Operator's Guide);
- Snow or water ingestion;
- Incidental or consequential damages, or damages of any kind including without limitation towing, storage, telephone, rental, taxi, inconvenience, insurance coverage, loan payments, loss of time, loss of income; and
- Damage resulting from studs installed on tracks if the installation does not conform to BRP's instructions.

#### **4) WARRANTY COVERAGE PERIOD**

This warranty will be in effect from the date of delivery to the first retail consumer or the date the product is first put into use, whichever occurs first and for a period of:

TWELVE (12) CONSECUTIVE MONTHS, for private or commercial use owners. However, the warranty coverage period on a snowmobile delivered between June 1<sup>st</sup> and December 1<sup>st</sup> of a given year will expire November 30<sup>th</sup> of the following year.

The repair or replacement of parts or the performance of service under this warranty does not extend the life of this warranty beyond its original expiration date.

Note that the duration and any other modalities of the warranty coverage are subject to the applicable national or local legislation in the customer's country.

#### **5) CONDITIONS TO HAVE WARRANTY COVERAGE**

This warranty coverage is available **only** if each of the following conditions has been fulfilled:

- The 2009 Ski-Doo snowmobile must be purchased as new and unused by its first owner from a BRP distributor/dealer authorized to distribute Ski-Doo snowmobiles in the country in which the sale occurred ("BRP distributor/dealer");
- The BRP specified pre-delivery inspection process must be completed and documented;
- The product must have undergone proper registration by an authorized BRP distributor/dealer;
- The 2009 Ski-Doo snowmobile must be purchased in the country in which the purchaser resides;
- Routine maintenance outlined in the Operator's Guide must be timely performed in order to maintain warranty coverage. BRP reserves the right to make warranty coverage contingent upon proof of proper maintenance.

BRP will not honour this limited warranty to any private use owner or commercial use owner if the preceding conditions have not been met. Such limitations are necessary in order to allow BRP to preserve both the safety of its products, and also that of its consumers and the general public.

## **6) WHAT TO DO TO OBTAIN WARRANTY COVERAGE**

The customer must cease using the snowmobile upon the appearance of an anomaly. The customer must notify a servicing BRP distributor/dealer within two (2) days of the appearance of a defect, and provide it with reasonable access to the product and reasonable opportunity to repair it. The customer must also present to the authorized BRP distributor/dealer, proof of purchase of the product and must sign the repair/work order prior to starting the repair in order to validate the warranty repair. All parts replaced under this limited warranty become the property of BRP.

Note that the notification period is subject to the applicable national or local legislation in customer's country.

## **7) WHAT BRP WILL DO**

BRP's obligations under this warranty are limited to, at its sole discretion, repairing parts found defective under normal use, maintenance and service, or replacing such parts with new genuine Ski-Doo parts without charge for parts and labor, at any authorized BRP distributor/dealer during the warranty coverage period under the conditions described herein. BRP's responsibility is limited to making the required repairs or replacements of parts. No claim of breach of warranty shall be cause for cancellation or rescission of the sale of the snowmobile to the owner.

In the event that service is required outside of the country of original sale, the owner will bear responsibility for any additional charges due to local practices and conditions, such as, but not limited to, freight, insurance, taxes, license fees, import duties, and any and all other financial charges, including those levied by governments, states, territories and their respective agencies.

BRP reserves the right to improve or modify products from time to time without assuming any obligation to modify products previously manufactured.

## **8) TRANSFER**

If the ownership of a product is transferred during the warranty coverage period, this warranty shall also be transferred and be valid for the remaining coverage period provided BRP or an authorized BRP distributor/dealer receives a proof that the former owner agreed to the transfer of ownership, in addition to the co-ordinates of the new owner.

## **9) CONSUMER ASSISTANCE**

In the event of a controversy or a dispute in connection with this limited warranty, BRP suggests that you try to resolve the issue at the dealership level. We recommend discussing the issue with the authorized distributor/dealer's service manager or owner. If further assistance is required, the distributor's service department should be contacted in order to resolve the matter. If the matter still remains unresolved then contact BRP at the address listed below.

**For countries within Europe, Middle East, Africa, Russia & CIS, please contact our European office:**

**BRP EUROPE N.V.**

Customer Assistance Center  
Skaldenstraat 125  
9042 Gent  
Belgium  
Tel.: + 32-9-218-26-00

**For Scandinavian countries, please contact our Finland office:**

**BRP FINLAND OY**

Service Department  
Ahjotie 30  
Fin-96320 Rovaniemi  
Finland  
Tel.: + 358 16 3208 111

**For all other countries, please contact your local distributor or our North America office:**

**BOMBARDIER RECREATIONAL PRODUCTS INC.**

Customer Assistance Center  
75, J.-A. Bombardier Street  
Sherbrooke, Québec J1L 1W3  
Tel.: 819 566-3366

You will find your distributor's coordinates on [www.brp.com](http://www.brp.com).

\* In certain countries, products are distributed and serviced by affiliates or subsidiaries of BRP.

© 2008 Bombardier Recreational Products Inc. All rights reserved.

® Registered trademark of Bombardier Recreational Products Inc.

---

# **BRP LIMITED WARRANTY FOR THE EUROPEAN ECONOMIC AREA: 2009 SKI-DOO® SNOWMOBILES**

## **1) SCOPE OF THE LIMITED WARRANTY**

Bombardier Recreational Products Inc. ("BRP")\* warrants its 2009 Ski-Doo snowmobiles sold by authorized BRP distributor/dealer (as hereinafter defined) in states members of the European Economic Area ("EEA") (which is comprised of the states member of the European Union plus Norway, Iceland and Liechtenstein) from defects in material or workmanship for the period and under the conditions described below. This limited warranty will become null and void if:

1. The snowmobile was used for racing or any other competitive activity, at any point, even by a previous owner; or
2. The snowmobile has been altered or modified in such a way so as to adversely affect its operation, performance or durability, or has been altered or modified to change its intended use.

All genuine Ski-Doo parts and accessories, installed by an authorized BRP distributor/dealer (at the time of delivery of the 2009 Ski-Doo snowmobile, carry the same warranty as that of the snowmobile.

## **2) LIMITATIONS OF LIABILITY**

THIS WARRANTY IS EXPRESSLY GIVEN AND ACCEPTED IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT THAT THEY CANNOT BE DISCLAIMED, THE IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFE OF THE EXPRESS WARRANTY. INCIDENTAL AND CONSEQUENTIAL DAMAGES ARE EXCLUDED FROM COVERAGE UNDER THIS WARRANTY. SOME JURISDICTIONS DO NOT ALLOW FOR THE DISCLAIMERS, LIMITATIONS AND EXCLUSIONS IDENTIFIED ABOVE, AS A RESULT, THEY MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH MAY VARY FROM COUNTRY TO COUNTRY, OR PROVINCE TO PROVINCE.

Neither the distributor, any BRP distributor/dealer nor any other person has been authorized to make any affirmation, representation or warranty regarding the product, other than those contained in this limited warranty, and if made, shall not be enforceable against BRP.

BRP reserves the right to modify this warranty at any time, being understood that such modification will not alter the warranty conditions applicable to the products sold while this warranty is in effect.

## **3) EXCLUSIONS – ARE NOT WARRANTED**

The following are not warranted under any circumstances:

- Normal wear and tear;
- Routine maintenance items, tune ups, adjustments;
- Damage caused by failure to provide proper maintenance and/or storage, as described in the Operator's Guide;

- Damage resulting from removal of parts, improper repairs, service, maintenance, modifications or use of parts not manufactured or approved by BRP or resulting from repairs done by a person that is not an authorized servicing BRP distributor/dealer;
- Damage caused by abuse, abnormal use, neglect, use of the product on surfaces other than snow, or operation of the product in a manner inconsistent with the recommended operation described in the Operator's Guide;
- Damage resulting from accident, submersion, fire, theft, vandalism or any act of God;
- Operation with fuels, oils or lubricants which are not suitable for use with the product (see the Operator's Guide);
- Snow or water ingestion;
- Incidental or consequential damages, or damages of any kind including without limitation towing, storage, telephone, rental, taxi, inconvenience, insurance coverage, loan payments, loss of time, loss of income; and
- Damage resulting from studs installed on tracks if the installation does not conform to BRP's instructions.

#### **4) WARRANTY COVERAGE PERIOD**

This warranty will be in effect from the date of delivery to the first retail consumer or the date the product is first put into use, whichever occurs first and for a period of:

TWENTY-FOUR (24) CONSECUTIVE MONTHS for private use owners, and TWELVE (12) CONSECUTIVE MONTHS for commercial use owners. However, the warranty coverage period on a snowmobile delivered between June 1<sup>st</sup> and December 1<sup>st</sup> of a given year will expire November 30<sup>th</sup> of the applicable year. A snowmobile is used commercially when it is used in connection with generating income or any work or employment during any part of the warranty period. A snowmobile is also used commercially when, at any point during the warranty period, it has commercial tags or is licensed for commercial use.

The repair or replacement of parts or the performance of service under this warranty does not extend the life of this warranty beyond its original expiration date.

Note that the duration and any other modalities of the warranty coverage are subject to the applicable national or local legislation in the customer's country.

#### **5) CONDITIONS TO HAVE WARRANTY COVERAGE**

This warranty coverage is available **only** if each of the following conditions has been fulfilled:

- The 2009 Ski-Doo snowmobile must be purchased as new and unused by its first owner from a BRP distributor/dealer authorized to distribute Ski-Doo products in the country in which the sale occurred ("BRP distributor/dealer");
- The BRP specified pre-delivery inspection process must be completed and documented;
- The product must have undergone proper registration by an authorized BRP distributor/dealer;



- The 2009 Ski-Doo snowmobile must be purchased within the EEA;
- Routine maintenance outlined in the Operator's Guide must be timely performed in order to maintain warranty coverage. BRP reserves the right to make warranty coverage contingent upon proof of proper maintenance.

BRP will not honour this limited warranty to any private use owner or commercial use owner if the preceding conditions have not been met. Such limitations are necessary in order to allow BRP to preserve both the safety of its products, and also that of its consumers and the general public.

## **6) WHAT TO DO TO OBTAIN WARRANTY COVERAGE**

The customer must cease using the snowmobile upon the appearance of an anomaly. The customer must notify a servicing BRP distributor/dealer within two (2) months of the appearance of a defect, and provide it with reasonable access to the product and reasonable opportunity to repair it. The customer must also present to the authorized BRP distributor/dealer, proof of purchase of the product and must sign the repair/work order prior to starting the repair in order to validate the warranty repair. All parts replaced under this limited warranty become the property of BRP.

Note that the notification period is subject to the applicable national or local legislation in customer's country.

## **7) WHAT BRP WILL DO**

BRP's obligations under this warranty are limited to, at its sole discretion, repairing parts found defective under normal use, maintenance and service, or replacing such parts with new genuine Ski-Doo parts without charge for parts and labor, at any authorized BRP distributor/dealer during the warranty coverage period under the conditions described herein. BRP's responsibility is limited to making the required repairs or replacements of parts. No claim of breach of warranty shall be cause for cancellation or rescission of the sale of the snowmobile to the owner.

In the event that service is required outside of the EEA, the owner will bear responsibility for any additional charges due to local practices and conditions, such as, but not limited to, freight, insurance, taxes, license fees, import duties, and any and all other financial charges, including those levied by governments, states, territories and their respective agencies.

BRP reserves the right to improve or modify products from time to time without assuming any obligation to modify products previously manufactured.

## **8) TRANSFER**

If the ownership of a product is transferred during the warranty coverage period, this warranty shall also be transferred and be valid for the remaining coverage period provided BRP or an authorized BRP distributor/dealer receives a proof that the former owner agreed to the transfer of ownership, in addition to the co-ordinates of the new owner.

## 9) CONSUMER ASSISTANCE

In the event of a controversy or a dispute in connection with this limited warranty, BRP suggests that you try to resolve the issue at the dealership level. We recommend discussing the issue with the authorized distributor/dealer's service manager or owner. If further assistance is required, the distributor's service department should be contacted in order to resolve the matter. If the matter still remains unresolved then contact BRP at the address listed below:

**For countries within Europe, Middle East, Africa, Russia & CIS, please contact our European office:**

**BRP EUROPE N.V.**

Customer Assistance Center  
Skaldenstraat 125  
9042 Gent  
Belgium  
Tel.: + 32-9-218-26-00

**For Scandinavian countries, please contact our Finland office:**

**BRP FINLAND OY**

Service Department  
Ahjotie 30  
Fin-96320 Rovaniemi  
Finland  
Tel.: + 358 16 3208 111

**For all other countries, please contact your local distributor or our North America office:**

**BOMBARDIER RECREATIONAL PRODUCTS INC.**

Customer Assistance Center  
75, J.-A. Bombardier Street  
Sherbrooke, Québec J1L 1W3  
Tel.: 819 566-3366

You will find your distributor's coordinates on [www.brp.com](http://www.brp.com).

\* In the EEA, products are distributed and serviced by BRP European Distribution S.A. and other affiliates or subsidiaries of BRP.

© 2008 Bombardier Recreational Products Inc. All rights reserved.

® Registered trademark of Bombardier Recreational Products Inc.

---

# PRIVACY OBLIGATION/DISCLAIMER

We wish to inform you that your coordinates will be used for safety and warranty purposes. Sometimes, we also use the coordinates of our clients to inform them about our products and to present them offers. Should you prefer not to receive information on our products, services and offers, please let us know by writing to the address below.

Also note that, from time to time, carefully selected and trustworthy organizations may be permitted to use the coordinates of our clients to promote quality products and services. If you prefer not to have your name and address released, please let us know by writing to the address below:

## **In Canada**

### **BOMBARDIER RECREATIONAL PRODUCTS INC.**

Warranty Department  
75, J.-A. Bombardier Street  
Sherbrooke, Québec J1L 1W3  
Fax Number: 819 566-3590

## **In USA**

### **BRP US INC.**

Warranty Department  
7575 Bombardier Court  
Wausau WI 54401  
Tel.: 715 848-4957

## **For Russia, CIS and the Middle East**

### **BRP EUROPEAN DISTRIBUTION**

After Sales Service Department  
Chemin de Messidor 5-7  
1006 Lausanne  
Switzerland  
Fax Number: + 41213187801

## **For Scandinavian and European countries**

### **BRP FINLAND OY**

Service Department  
Ahjotie 30  
FIN-96320 Rovaniemi  
Finland  
Tel.: + 358 16 3208 111

## **For all other countries, please contact A) or B)**

**A)** Your respective distributor (you will find his coordinates on [www.brp.com](http://www.brp.com)).

**B)** Our North American office:

### **BOMBARDIER RECREATIONAL PRODUCTS INC.**

Warranty Department  
75, J.-A. Bombardier Street  
Sherbrooke, Québec J1L 1W3  
Canada  
Fax Number: 819 566-3590

---

# CHANGE OF ADDRESS/OWNERSHIP

If your address has changed or if you are the new owner of the vehicle, be sure to notify BRP by either:

- Mailing one of the following card below;
- **North America Only:** calling at 715 848-4957 (USA) or 819 566-3366 (Canada);
- Notifying an authorized SKI-DOO dealer.

## **In Canada**

### **BOMBARDIER RECREATIONAL PRODUCTS INC.**

Warranty Department  
75, J.-A. Bombardier Street  
Sherbrooke, Québec J1L 1W3  
Fax Number: 819 566-3590

## **In USA**

### **BRP US INC.**

Warranty Department  
7575 Bombardier Court  
Wausau WI 54401  
Tel.: 715 848-4957

## **For Russia, CIS and the Middle East**

### **BRP EUROPEAN DISTRIBUTION**

After Sales Service Department  
Chemin de Messidor 5-7  
1006 Lausanne  
Switzerland  
Fax Number: + 41213187801

## **For Scandinavian and European countries**

### **BRP FINLAND OY**

Service Department  
Ahjotie 30  
FIN-96320 Rovaniemi  
Finland  
Tel.: + 358 16 3208 111

## **For all other countries, please contact A) or B)**

**A) Your respective distributor (you will find his coordinates on [www.brp.com](http://www.brp.com)).**

**B) Our North American office:**

### **BOMBARDIER RECREATIONAL PRODUCTS INC.**

Warranty Department  
75, J.-A. Bombardier Street  
Sherbrooke, Québec J1L 1W3  
Canada  
Fax Number: 819 566-3590







**Bombardier Recreational Products Inc.**  
565 de la Montagne Street  
Valcourt, Québec, Canada J0E 2L0  
T 450.532.2211  
[www.brp.com](http://www.brp.com)

Date: August 27, 2008

## Addendum to the 2009 Ski-Doo® Operator's Guide

Dear Ski-Doo owner,

The 2009 Ski-Doo Summit™ Hillclimb model is designed for special purposes and may not comply with trail provincial/state regulations due to its overall width. The skis can be set at two different width positions. The ski stance can be set at 105.6 cm (41.6 in) or 109.8 cm (43.25 in). These settings will result in an overall width of 123.1 cm (48.5 in) at the narrowest and 124.7 cm (50 in) at the widest.

Before riding your snowmobile on a trail, you must be aware of the local trail regulations regarding the width limitations in force in the concerned area.

Concerning this matter, the following label has been affixed on your snowmobile.



Please, keep this notice with your Operator's Guide.

Sincerely,  
After-Sales Service  
Bombardier Recreational Products Inc.



520 000 900

CA

OPERATOR'S GUIDE, REV-XP / ENGLISH  
GUIDE DU CONDUCTEUR, REV-XP / ANGLAIS

FAIT AU / MADE IN CANADA

U/M:P.C.