

# SEATING LOCATIONS



**ALUMACraft**<sup>®</sup>

P/N 3019-0022703  
REV. APR. 2024

## SEATING POSITIONS BY MODEL - UNITED STATES

Please reference the capacity plate installed on your boat for the number of persons and weight capacity specific to your boat. Never exceed the number of persons or weight capacity stated on the capacity plate. As the captain, you are responsible for properly loading the boat and ensuring your passengers are safely seated and secure. Keep in mind the limits defined on capacity plates apply in good to moderate weather conditions. In rough waters, keep the weight well below the limit. In ideal weather conditions, it is recommended that you distribute your load evenly, keep weight low, and avoid abrupt changes in distribution. This is especially important if your boat's capacity is fully used or if weather conditions deteriorate. It is also important to remember that people represent a "live" load and moving about affects a boat quite differently than static loads. In general, shift human or other weight only after stopping or slowing.

Each passenger must be seated and secure while the boat is underway. Swivel seats, if applicable, must be locked and secured while the boat is underway. Ensure all gates are closed and secured. Occupy designated seating positions first before utilizing alternate seating positions.

### **WARNING**

**Do not attempt to reboard while the engine is running. Swimmers must not exit or enter the boat when the engine is running or the propeller is in motion.**

The number of persons and weight capacities may vary depending on the country in which your boat is operated. If you have questions regarding the locations of passengers or weight capacity for your boat, please contact your local Manitou dealer for additional information.

### **WARNING**

**Operating, servicing and maintaining a recreational marine vessel can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, service your vessel in a well-ventilated area and wear gloves or wash your hands frequently when servicing this vessel. For more information go to [www.P65warnings.ca.gov/marine](http://www.P65warnings.ca.gov/marine)**



## TABLE OF CONTENTS

Trophy Sport.....	2
Competitor Sport .....	2
Competitor SC.....	3
Classic .....	4
Voyageur.....	4
Escape .....	5
V-Series.....	5




# TROPHY SPORT/COMPETITOR SPORT

175 Max Deck [6 Persons]



175 Outboard [6 Persons]




185 Max Deck [6 Persons]



185 Outboard [6 Persons]



195 Outboard [8 Persons]




205 Outboard [8 Persons]






# COMPETITOR SC


175 Max Deck [6 Persons]




175 Outboard [6 Persons]




185 Max Deck [6 Persons]




185 Outboard [6 Persons]



195 Outboard [8 Persons]



205 Outboard [8 Persons]



## CLASSIC

165 CS [5 Persons]



165 Sport [5 Persons]



165 Tiller [5 Persons]



## VOYAGEUR

175 CS [6 Persons]



175 Sport [5 Persons]



## ESCAPE


165 CS [5 Persons]

145 CS [4 Persons]



165 Tiller [5 Persons]



145 Tiller [4 Persons]



## V-SERIES

V14 w/floor [5 Persons]

V16 w/floor [5 Persons]





# BRP REIMAGINES THE WAY YOU ACCESS YOUR WORLD

Alumacraft is one of many success stories from BRP, the global company behind some of the most daringly innovative products and experiences that move you. Because it's not about the destination, it's about the journey – yours.

Discover our brands:

***ski-doo* LYNX SEA-DOO CAN-AM ROTAX ALUMACraft. MANITOU. QUINTREX**

[www.brp.com](http://www.brp.com)

